



Actuator controls

AUMATIC AC 01.1/ACExC 01.1

Control:

Parallel
Profibus DP
Profibus DP with FO
Modbus
Modbus with FO
DeviceNet
→ Foundation Fieldbus



Read operation instructions first

- Observe safety instructions.

Reference documents:

- Operation instructions (assembly, operation, commissioning) for actuator
- Manual (Fieldbus device integration) AUMATIC AC 01.1/ACExC 01.1 Foundation Fieldbus
Can be downloaded from the Internet (www.auma.com) or ordered directly from AUMA (addresses from page 94).

Table of contents		Page
1	Safety instructions	5
1.1	General notes on safety	5
1.2	Range of application	6
1.3	Warnings and symbols	6
2	Identification	7
2.1	Name plate	7
2.2	Short description	8
3	Operation	9
3.1	Local operation	9
3.2	Operation from REMOTE	9
3.3	Menu navigation via push buttons (for settings and indications)	10
3.3.1	Short overview: functions of the push buttons	10
3.3.2	Structural design and navigation	11
3.4	Operation and setting via AUMA COM-AC programming software	12
3.4.1	Operation setting via COM-AC	12
3.5	Password change	13
3.6	Language change in the display	14
3.7	LCD contrast setting of the display (applies only to controls with green display)	14
4	Indications	15
4.1	Status indications in the display	15
4.1.1	Status indication S0/S6 - operation	15
4.1.2	Status indication S4 - torque	16
4.2	Torque indication: edit	16
4.3	Electronic name plate	17
4.3.1	Display indication: enable view	17
4.3.2	Electronic name plate: view	17
4.4	Indication lights/LEDs	19
4.4.1	Standard indication	19
4.4.2	Configuration of the signals: view/edit	20
4.4.3	Blinking behaviour of indication lights/LEDs: view/edit	21
5	Signals	22
5.1	Signals via fieldbus	22
5.1.1	Configuration of adjustable (user-definable) signals	22
5.2	Feedback via output contacts (binary) - (option)	23
5.2.1	Configuration for output contacts 1 to 5: view/edit	23
5.2.2	Configuration alarm contacts (collective fault signal): view/edit	25
5.2.3	Output contacts 1 to 5: use as running indication (blinker)	26
5.3	Feedback signals (analogue) - (option)	27
5.3.1	Position transmitter/actual position source (E2): view	27
5.3.2	Source of the torque signal E6: view	28
5.3.3	Feedback signals (configuration) via analogue output 1: view	28
5.3.4	Signal range at the analogue output 1: view/edit	29
5.3.5	Feedback signals (configuration) via analogue output 2: view	30
5.3.6	Signal range at the analogue output 2: view/edit	30

	Page
6 Operation mode	31
6.1 Operation mode OFF	31
6.2 Operation mode LOCAL	32
6.2.1 Push-to-run operation or self-retaining: set for the operation mode LOCAL	32
6.3 Operation mode REMOTE	33
6.3.1 Push-to-run operation or self-retaining: set for operation mode REMOTE	33
6.4 Operation mode EMERGENCY	34
6.4.1 Operation mode (type of duty) activation for an emergency operation	34
6.4.2 EMERGENCY operation: switch on or off/signal behaviour definition	35
6.4.3 Actuator behaviour definition in case of an emergency operation	35
6.4.4 EMERGENCY position definition	36
6.4.5 Motor protection and/or torque switching: by-pass	36
6.5 Fault State behaviour in case of bus communication loss	37
6.6 Failure behaviour in case of analogue signal loss (option)	37
7 Functions	40
7.1 Type of seating: check/edit end positions	40
7.2 Torque switching: check/set	41
7.3 Limit switching setting	42
7.4 Intermediate positions (option)	43
7.4.1 Display indication: enable view	43
7.4.2 Intermediate positions: switch on or off	44
7.4.3 Intermediate position definition	44
7.4.4 Operation behaviour = actuator behaviour definition	45
7.4.5 Intermediate positions: set the signalling	45
7.5 Intermediate positions with multiport valve function (option)	47
7.5.1 Check: Multiport valve function available?	47
7.5.2 Check: Positioner active?	48
7.5.3 Display indication: enable view	48
7.5.4 Intermediate positions: switch on or off	48
7.5.5 Intermediate position setting	48
7.5.6 Operation behaviour = actuator behaviour definition	49
7.5.7 Intermediate positions signalling	49
7.5.8 Intermediate positions in LOCAL: direct approach without stopping	49
7.6 Positioner (operation mode SETPOINT MODE)	50
7.6.1 Adaptive behaviour: switch on or off	50
7.6.2 Overrun (inner dead band): set manually	51
7.6.3 Max. error variable (outer dead band): set manually	52
7.6.4 Dead time setting	52
7.6.5 Closing fully/opening fully (end position tolerance for setpoint E1)	53
7.6.6 Open-close duty (REMOTE) or modulating duty (SETPOINT) selection	53
7.6.7 Source of setpoint E1: view	54
7.6.8 Input range of setpoint 1: view/edit	55
7.7 Stepping mode (option)	56
7.7.1 Display indication: enable view	56
7.7.2 Stepping mode: switch on or off	57
7.7.3 Stepping range setting (start and end of stepping mode).	57
7.7.4 ON and OFF times setting	58
7.8 Local controls enable function (option)	59
7.8.1 Selector switch functions: enable/disable	59
7.9 EMERGENCY STOP function (option)	60
7.9.1 Description of the functions	60
7.9.2 Feedback signals on the display	61
7.9.3 Feedback signals setting via output contacts	61
7.9.4 Feedback signal setting via LEDs	61

	Page
7.10 Foundation Fieldbus interface	62
7.11 External inputs for bus (option)	63
7.11.1 Signals assignation for operation commands	63
7.12 Combination fieldbus/standard interface (option)	66
7.13 Monitoring and failure functions	67
7.13.1 Torque monitoring	67
7.13.2 Motor protection (thermal monitoring)	68
7.13.3 Monitoring of the max. number of starts per hour and max. running time per hour	69
7.13.4 Operating time monitoring	71
7.13.5 Reaction monitoring	72
7.13.6 Phase failure monitoring	73
8 Corrective action	74
8.1 Fault indications and warning indications	74
8.1.1 Status indication S0 - faults and warnings	74
8.1.2 Status indication S1 - faults	75
8.1.3 Status indication S2 - warnings	76
8.1.4 Status indication S3 - causes for not ready remote	77
8.2 Diagnostics	78
8.2.1 Operating data logging	78
8.2.2 Diagnostic indications (D) via the display	80
8.3 Troubleshooting	91
8.3.1 Problems with position feedback/indication E2 (from actuator)	91
8.3.2 Display hardly readable or illegible	91
8.3.3 Actuator does not run	91
8.3.4 Actuator does only operate from local	91
8.3.5 Actuator is not switched off by limit seating in direction CLOSE or OPEN	91
Index	92
Parameter index and indications on the display	93
Addresses	94

1 Safety instructions

1.1 General notes on safety

Standards/directives	<p>AUMA products are designed and manufactured in compliance with recognised standards and directives. This is certified in a declaration of incorporation and a declaration of conformity.</p> <p>The end user or the contractor of the plant must observe national laws and regulations regarding assembly, electrical connection, and commissioning on site.</p> <p>This includes in particular the fulfilment of the requirements in standards and directives for potentially explosive areas, such as e.g. EN 60079-17 "Inspection and maintenance of electrical installations in hazardous areas (other than mines) (IEC 60079-17:2002)".</p> <p>This includes, in particular the observance of the applicable configuration directives for fieldbus applications.</p>
Safety instructions/warnings	<p>All personnel working with this device must be familiar with the safety and warning instructions in this manual and observe the instructions given. Safety instructions and warning signs on the device must be observed to avoid personal injury or property damage.</p>
Qualification of staff	<p>Assembly, electrical connection, commissioning, operation, and maintenance must be carried out exclusively by suitably qualified personnel authorised by the end user or contractor of the plant.</p> <p>Prior to working on this product, the staff must have thoroughly read and understood these instructions and, furthermore, know and observe officially recognised rules regarding occupational health and safety.</p> <p>Work performed in potentially explosive atmospheres is subject to special regulations which have to be observed. The end user or contractor of the plant are responsible for respect and control of these regulations, standards, and laws.</p>
Commissioning	<p>Prior to commissioning, it is important to check that all settings are in compliance with the requirements of the application. Incorrect settings might present a danger to the application, e.g. cause damage to the valve or the installation.</p> <p>The manufacturer will not be held liable for any consequential damage. Such risk lies entirely with the user.</p>
Safe operation	<p>Prerequisites for safe and smooth operation:</p> <ul style="list-style-type: none"> • Correct transport, proper storage, mounting and installation, as well as careful commissioning. • Exclusively operate the device if it is in perfect condition while observing these instructions. • Immediately inform about any faults and damage and allow for corrective measures. • Observe recognised rules for occupational health and safety.
Protective measures	<p>The end user or the contractor are responsible for implementing required protective measures on site, such as enclosures, barriers, or personal safety equipment for the staff.</p>
Maintenance	<p>Any device modification requires the consent of the manufacturer.</p>

1.2

Range of application

AUMA actuator controls are exclusively designed for the operation of AUMA actuators.

Other applications require explicit (written) confirmation by the manufacturer.

The following applications are not permitted, e.g.:

- motor activation
- pump activation

No liability can be assumed for inappropriate or unintended use.

Observance of these operation instructions is considered as part of the device's designated use.

1.3

Warnings and symbols

The following references and symbols are used in these instructions:

NOTICE

Potentially hazardous situation. Failure to observe this warning may result in property damage.

Information

The term **Information** preceding the text indicates important notes and information.

For assembly, operation, and commissioning, observe the additional safety and warning instructions of the reference documents (page 2).



Symbol for CLOSED.



Symbol for OPEN.



Via the menu to parameter

Describes the path within the menu to the parameter. By using the push buttons of the local controls you may quickly find the desired parameter in the display.



Description of the parameter settings/indications

Describes the setting/viewing possibilities of a parameter.




Step by step

Provides a detailed description of each step for setting/viewing the parameter.

2 Identification


2.1 Name plate

Each device is equipped with a name plate (figure 1).



1 Name plate controls

Identification data on the controls' name plate:



- 1 Type and size of the controls
- 2 Commission number
- 3 Wiring diagram/control

Type and size These instructions apply to the following controls types:
Type: AC = actuator controls AUMATIC
Size: 01.1

Commission number An order-specific commission number is assigned to each device. You can use this number to download the wiring diagram, inspection records and further information from the Internet (www.auma.com).

Wiring diagram/control Controlling the actuator controls is performed via a **Foundation Fieldbus interface** , if the 11th position in the ACP wiring diagram contains the letters B or C. Example: ACP 11F1-2M0—**B**000.

The actuator controls are designed for the **Non-Intrusive** version (refer also to page 8), if the 7th position in the ACP wiring diagram contains the figure M, e.g.: ACP 11F1-2**M**0—B000.

2.2 Short description


Actuator controls	<p>The AUMATIC actuator controls is used to operate AUMA actuators and is supplied ready for use.</p> <p>The controls can be mounted directly to the actuator but also separately on a wall bracket.</p> <p>The functions of the AUMATIC controls include standard valve control in OPEN - CLOSE duty, positioning, process control, logging of operating data, diagnosis functions right through control via fieldbus.</p>
Local controls/ COM-AC/fieldbus	<p>Operation, setting, and display can be performed on site directly at the controls or alternatively from REMOTE via a fieldbus interface.</p> <p>On site it is possible to</p> <ul style="list-style-type: none">• operate the actuator via the local controls (push buttons and display) and perform settings (contents of these instructions).• read in or out data or modify and save settings via the AUMA COM-AC programming software (option), using a computer (laptop or PC). <p>Depending on the version, the connection between computer and AUMATIC can be made with cable (infra-red interface) or without cable (Bluetooth interface)(not included in these instructions).</p>
Intrusive – Non-Intrusive	<p>Intrusive version:</p> <ul style="list-style-type: none">• Limit and torque setting is performed via switches in the actuator. <p>Non-Intrusive version:</p> <ul style="list-style-type: none">• Limit and torque setting is performed via the controls, actuator and controls housings do not have to be opened. <p>For this purpose, the actuator is equipped with an MWG (magnetic limit and torque transmitter), also supplying analogue torque feedback signals/torque indication.</p>

3 Operation

3.1 Local operation


The local operation of the actuator is performed using the push buttons (figure 3).

Figure 3



- | | |
|---------------------|--------------------------|
| 1 Push button OPEN | 4 Push button Reset |
| 2 Push button STOP | 5 Selector switch |
| 3 Push button CLOSE | 6 Indication lights/LEDs |

→ Set selector switch (5) to position **Local control** (LOCAL).



The actuator can now be operated using the push buttons (1 – 3).


- | | |
|-------------------------------------|------------------------|
| 1. Run actuator in direction OPEN: | Press push button (1). |
| 2. Stop actuator: | Press push button (2). |
| 3. Run actuator in direction CLOSE: | Press push button (3). |

Information

The OPEN - CLOSE operation commands can be given either in push-to-run operation or in the self-retaining mode.

3.2 Operation from REMOTE

→ Set selector switch to position **Remote control** (REMOTE).




Now, it is possible to operate the actuator by remote control via operation commands (OPEN, STOP, CLOSE) or via analogue setpoint (e.g. 0 – 20 mA).

Information


- Use the **MODE** input (refer to wiring diagram) to select between **REMOTE MODE** (open-close duty) and **SETPOINT MODE** (modulating duty).
- The **FAILURE MODE** and **EMERGENCY MODE** operation modes are set via parameters.

3.3 Menu navigation via push buttons (for settings and indications)

The push buttons of the local controls (figure 4) are used to view, edit, and show various indications on the display.



→ Set selector switch (5) to position **0** (OFF).



Now, settings and indications can be performed via the push buttons (1 – 4).

3.3.1 Short overview: functions of the push buttons


Table 1	
Push buttons	Functions
▲ ▼	Scrolling within a group (The triangles ▲ ▼ in the display show the direction of scrolling.)
	Change values
	Enter figures from 0 to 9
←	Confirm the selection to go to a new menu/subgroup.
C	Cancel process
	Return to previous display: press briefly
	Change to another group (S, M, D) - press for approx. 3 seconds until group M0 is displayed. - hold down for more than 3 seconds until group D0 is displayed (thereby, group M is skipped).

3.3.2 Structural design and navigation

The indications on the display are divided into 3 groups:

- Group S = status indications
- Group M = menu (settings)
- Group D = diagnostic indications

The active group is displayed on the top right corner of the display.



Change groups

Change from group S to group M:

→ Press **C** push button and hold it down for approx. 3 seconds until group M0 appears.

Change from group S to group D:

→ Press **C** push button and hold it down until group D0 appears (group M is hereby skipped).


Change from any group M or D back to group S:

→ Briefly press **C**.

Scrolling

→ Press **▼▲**:


The triangles **▼▲** in the top left corner of the display indicate the possible scrolling direction (within one group) of scrolling.



Enter the password

In the menu (group M), the settings are protected by a password. To change the parameters, a password must first be entered. The following default password is set in the factory: 0000.

After selecting **EDIT**, the following is displayed:




1. Select figures 0 to 9: Press **▼▲**.
2. Move to the next position: Press **↵**.
3. Repeat steps 1 and 2 for all four digits.
4. To cancel a process: Press **C**.

Information

If no input is received over a longer period of time (approx. 10 min), the controls automatically returns to the status indication S0.

3.4 Operation and setting via AUMA COM-AC programming software


Data from the actuator can easily be imported, exported and settings changed and saved using the AUMA COM-AC programming software (option) in combination with a computer. Depending on the version, the connection between computer and AUMATIC can be performed with cable (infra-red interface) or without cable (Bluetooth interface) (not included in these instructions) .



3.4.1 Operation setting via COM-AC

The COM-AC software can transmit the operation commands OPEN, STOP, CLOSE to the actuator.

- ➡ **Via the menu to parameter:**
MAIN MENU (M0)
 SETTINGS (M1)
 COM-AC CONTROL (M1P0)
 LOCAL CLIENT (M1P10)



Default value: REMOTE AND LOCAL

Description of the parameter settings:

REMOTE AND LOCAL

The actuator can be operated in selector switch position LOCAL CONTROL or REMOTE CONTROL via the COM-AC with the OPEN, STOP, CLOSE commands.

LOCAL CONTROL ONLY

The actuator can be operated in selector switch position LOCAL CONTROL via the COM-AC with the OPEN, STOP, CLOSE commands.
No operation control is possible in selector switch position REMOTE CONTROL.

3.5 Password change

The following default password is set in the factory: 0000.




Via the menu to parameter:

MAIN MENU (M0)
SETTINGS (M1)
CHANGE PASSWORD (M1D)




Step by step:


1. Set selector switch to position **0** (OFF).




2. Press **C** and hold down it for approx 3 seconds.
Display indicates:




3. Press **▼**.
Display indicates:




4. Press **←**.
Display indicates:



5. Select CHANGE PASSWORD (M1D) using **▼**.
Display indicates:



6. Press **←**.
Display indicates:




7. Enter password (see page 11).

3.6 Language change in the display



Via the menu to parameter:

MAIN MENU (M0)
LANGUAGE/CONTRAS (M00)
LANGUAGE (M010)



Default value: GERMAN

Setting range: GERMAN, PORTUGUESE, ITALIAN, SPANISH,
FRENCH, ENGLISH, TUERKCE, POLSKI, MAGYAR


3.7 LCD contrast setting of the display (applies only to controls with green display)

To improve the legibility of the display under unfavourable lighting conditions, the contrast may be adjusted.
This setting is only possible for green displays. The contrast setting has no effect on the blue display.



Via the menu to parameter:

MAIN MENU (M0)
LANGUAGE/CONTRAST M00)
LCD CONTRAST (M011)



Default value: 80 %

Setting range: 0 % to 100 %

Information

Alternatively, the LCD contrast can be set as follows:

1. Press **C** and hold it down.
The menus S, M, D are skipped.
After approximately 10 seconds, the LED display will continuously change from bright to dark and vice versa.
2. Release push button
The current brightness level is saved.

4 Indications

4.1 Status indications in the display

The status indications on the display locally indicate the current operation states in plain text or as bar chart.

Table of contents:

4.1.1 Status indication S0/S6 - operation

4.1.2 Status indication S4 - torque

Further information on this topic:

For status indications regarding faults and warnings, refer to pages 74 et seqq.


4.1.1 Status indication S0/S6 - operation

Information

For actuators equipped with active process controllers in the logic sub-assembly, status indication S6 is displayed instead of status indication S0 in selector switch position REMOTE. The description below applies to both indications (S0 and S6).


Operation mode display

Line 1 indicates the current operation mode (LOCAL MODE, OFF, SETPOINT MODE, ...)




Operation command/ setpoint display

Line 2 indicates currently incoming operation commands (OPEN, STOP, CLOSE) or the setpoint E1 in % of the total travel.



Valve position display


Line 3 indicates the valve position in % of the travel. This indication is only available if the actuator is equipped with a position transmitter.



0 % = Actuator is in end position CLOSED
100 % = Actuator is in end position OPEN

End position/running indication

Line 4 indicates the current actuator status.



Description of indications in line 4:


RUNNING OPEN

Actuator runs logically OPEN (remains set during operation pauses).

- RUNNING CLOSE**
Actuator runs logically CLOSE (remains set during operation pauses).
- OPEN POSITION**
End position OPEN reached.
- CLOSED POSITION**
End position CLOSED reached.
- SETPOINT POSITION**
Setpoint (modulating actuators only).
- ↓ **Description of the fault signals:**
See page 74.

4.1.2 Status indication S4 - torque

This indication is only available if the actuator is equipped with an MWG (magnetic limit and torque transmitter); refer to page 8.
A deflection to the left side indicates torque in direction CLOSE.
A deflection to the right side indicates torque in direction OPEN.




Example: SA 07.5 with 20 – 60 Nm
100 % corresponds to 60 Nm of the nominal torque.
50 % corresponds to 30 Nm of the nominal torque.

4.2 Torque indication: edit

The torque value can be displayed in percent, Newtonmeter (Nm) or in Lbs/ft.

- ➡ **Via the menu to parameter:**
MAIN MENU (M0)
 SETTINGS (M1)
 LOCAL CONTROLS (M13)
 TORQUE INDICATION (M1317)



Default value: NEWTONMETER

- ↓ **Description of the parameter settings:**
- PERCENT**
Indication of the nominal torque in percent
- NEWTONMETER**
Indication in Nm
- LBS . FT .**
Indication in Lbs./ft.

4.3 Electronic name plate

The electronic name plate provides information about the order data (important for enquiries in the factory)

Table of contents:

4.3.1 Display indication: enable view

4.3.2 Electronic name plate: view

4.3.1 Display indication: enable view

The EL. NAME PLATE setting must be set to VIEW ENABLED:




Via the menu to parameter:

MAIN MENU (M0)

CONFIGURATION (M4)

SPECIAL FUNCTIONS (M40)

EL. NAME PLATE (M4013)



Default value: VIEW ENABLED



Description of the parameter settings:

VIEW NOT ENABLED

The electronic name plate is not shown in the display.

VIEW ENABLED

The electronic name plate is shown in the display.

4.3.2 Electronic name plate: view



Via the menu to parameter:

MAIN MENU (M0)

EL. NAME PLATE (M3)

ORDER DATA (M30)

PRODUCT DATA (M31)

PROJECT DATA (M32)

SERVICE DATA (M33)




Table 2	
Order data (M30)	
COMMISS NO. AUMATIC	set in the factory
COMMISS NO. ACTUATOR	set in the factory
KKS NO.	set in the factory
VALVE NO.	adjustable
PLANT NO.	adjustable
Product data (M31)	
PRODUCT TYPE	set in the factory
WORKS NO. ACTUATOR	set in the factory
WORKS NO. AUMATIC	set in the factory
LOGIC SFTWR. VER.	software version of the logic, set in the factory
LOGIC HRDWR. VER.	hardware version of the logic, set in the factory
DATE OF FINAL TEST	set in the factory
WIRING DIAGRAM	set in the factory
TERMINAL PLAN	set in the factory

Project and user specific data are freely definable and can be entered by the user:

Table 3	
Project data (M32)	
PROJECT NAME	adjustable (fields for customer input)
CUSTOMER FIELD 1	adjustable (fields for customer input)
CUSTOMER FIELD 2	adjustable (fields for customer input)

Service information such as the AUMA service phone number and the AUMA Internet address can be indicated here:

Table 4	
Service data (M33)	
SERVICE PHONE	set in the factory
INTERNET ADDRESS	www.auma.com, set in the factory
SERVICE TEXT 1	can only be changed by service technician
SERVICE TEXT 2	can only be changed by service technician

4.4 Indication lights/LEDs

The indication lights/LEDs locally display the different operation states as optical signal. The assignment of signals is freely selectable.

Table of contents:

4.4.1 Standard indication

4.4.2 Configuration of the signals: view/edit

4.4.3 Blinking behaviour of indication lights/LEDs: view/edit

4.4.1 Standard indication

Figure 6 shows the indication lights/LEDs on the local controls:






Table 5 describes the standard indication.


Table 5		
LED 1 (left) ( symbol)	illuminated	Actuator is in end position CLOSED
	blinking	Running indication: Actuator runs in direction CLOSE
LED 2 (T)	illuminated	Torque fault CLOSE
LED 3 (Th)	illuminated	Motor protection tripped
LED 4 (T)	illuminated	Torque fault OPEN
LED 5 (right) ( symbol)	illuminated	Actuator is in end position OPEN
	blinking	Running indication: Actuator runs in direction OPEN
LED 6 (BT) (option)	illuminated	Bluetooth connection available

Information

The behaviour (blinking/illuminated) can be changed via the `BLINKER` parameter.

4.4.2 Configuration of the signals: view/edit

➡ **Via the menu to parameter:**
MAIN MENU (M0)
 SETTINGS (M1)
 LOCAL CONTROLS (M13)
 LED 1 (LEFT HAND) (M1312)
 LED 2 (M1313)
 LED 3 (M1314)
 LED 4 (M1315)
 LED 1 (RIGHT HAND) (M1316)




Default values: LED 1 (LEFT HAND) = CLOSING BLINK
LED 2 = TORQUE FAULT (CLOSE)
LED 3 = THERMO FAULT
LED 4 = TORQUE FAULT (OPEN)
LED 5 (RIGHT HAND) = OPENING BLINK

Information Table 8, page 23 describes the signals which can be assigned to the LEDs. Table 8 applies to both the LEDs and the output contacts.

4.4.3 Blinking behaviour of indication lights/LEDs: view/edit**Via the menu to parameter:**

MAIN MENU (M0)
 SETTINGS (M1)
 LOCAL CONTROLS (M13)
 BLINKER (M1311)



Default value: OFF IN MIDPOSITION

**Description of the parameter settings:****OFF**

Blinker is switched off.

LIT IN MIDPOSITION

Table 6		
LED 1 only (yellow)	illuminated	Actuator is in end position CLOSED
LED 1 (yellow)	blinking	Actuator runs in direction CLOSE (running indication)
LED 5 only (green)	illuminated	Actuator is in end position OPEN
LED 5 (green)	blinking	Actuator runs in direction OPEN (running indication)

OFF IN MIDPOSITION

Table 7		
LED 1 (yellow)	illuminated	Actuator is in end position CLOSED
	blinking	Actuator runs in direction CLOSE (running indication)
LED 5 (green)	illuminated	Actuator is in end position OPEN
	blinking	Actuator runs in direction OPEN (running indication)

Information

The BLINKER parameter also influences the blinking behaviour of output contacts 1 to 5 if they are used as a running indication.

5 Signals

5.1 Signals via fieldbus

Feedback signals via Foundation Fieldbus can be configured.
The configuration is only defined via the transducer blocks and/or the function blocks.

Information The DD (Device Description) can be downloaded from the Internet:
www.auma.com

Please refer to the “Manual (Device integration Fieldbus) AUMATIC AC 01.1/ACExC 01.1 Foundation Fieldbus” regarding the feedback signals via Foundation Fieldbus and the parameter configuration via the fieldbus interface.

Table of contents:

5.1.1	Configuration of adjustable (user-definable) signals: view
5.1.2	Configuration of fault signals: view

5.1.1 Configuration of adjustable (user-definable) signals

The AUMATIC contains 3 function blocks (DIFB) allowing the user to configure 8 signals each out of the predefined set of signals. Configuration is exclusively defined via a Foundation Fieldbus configuration software. For further information, please refer to “Manual (Device integration Fieldbus) AUMATIC AC 01.1/ACExC 01.1 Foundation Fieldbus”.

5.2 Feedback via output contacts (binary) - (option)

These feedback signals are only available if a parallel interface is available in addition to the fieldbus interface (refer to page 66).

The output contacts can be used to indicate operation modes of the actuator or the controls as binary signals. The signals can be freely assigned. Example:

Output contact open = no thermal fault

Output contact closed = thermal fault in actuator

The output contacts are denominated in the wiring diagram as follows:

- Output contacts 1 to 5: DOUT1 to DOUT5
- Alarm contacts: NC fault/NO ready

Table of contents:

5.2.1	Configuration for output contacts 1 to 5: view/edit
5.2.2	Configuration for alarm contacts (collective fault signal): view/edit
5.2.3	Output contacts 1 to 5: use as running indication (blinker)

5.2.1 Configuration for output contacts 1 to 5: view/edit

Information Fault signals can be issued via the `ALARM CONTACT` parameter, other signals via the output contacts 1 to 5.



Via the menu to parameter:

MAIN MENU (M0)

SETTINGS (M1)

I/O 1 (M14)


OUTPUT CONTACT 1 (M1412)

OUTPUT CONTACT 2 (M1413)

OUTPUT CONTACT 3 (M1414)

OUTPUT CONTACT 4 (M1415)

OUTPUT CONTACT 5 (M1412)



Default values:

- OUTPUT CONTACT 1 = END POSITION OPEN
- OUTPUT CONTACT 2 = END POSITION CLOSED
- OUTPUT CONTACT 3 = SELECTOR SWITCH REMOTE
- OUTPUT CONTACT 4 = TSC FAULTS
- OUTPUT CONTACT 5 = TSO FAULTS

Table 8 shows the signal descriptions for the LEDs and the output contacts:

Table 8	
Signal	Description
NOT USED	No signals
CLOSED POSITION	Signals LSC (WSR) or LSC (WSR) and TSC (DSR) (depending on type of seating)
OPEN POSITION	Signals LSO (WOEL) or LSO (WOEL) and TSO (DOEL) (depending to type of seating)
RUNNING CLOSE	Actuator runs logically CLOSE
RUNNING OPEN	Actuator runs logically OPEN

Signal	Description
ACTUATOR MOVING	Actuator is running from LOCAL, REMOTE, or in manual operation (without position transmitter, only LOCAL or REMOTE operation are indicated).
LSC (WSR)	Limit switch CLOSE operated
LSO (WOEL)	Limit switch OPEN operated
TSC (DSR)	Torque switch CLOSE operated
TSO (DOEL)	Torque switch OPEN operated
THERMO FAULT	Motor protection has tripped (reset may be necessary)
TORQUE FAULT (CLOSE)	Torque fault in direction CLOSE occurred
TORQUE FAULT (OPEN)	Torque fault in direction OPEN occurred
TORQUE FAULT (GEN.)	Torque fault CLOSE or OPEN (combined signal)
SETPOINT E1 LOSS	Nominal value signal is by 0.3 mA lower than the lowest set value
FEEDBACK E2 LOSS	Actual position signal is by 0.3 mA lower than the lowest set value
SPEED E3 LOSS	not available
TORQUE E6 LOSS	Torque signal is by 0.3 mA lower than the lowest set value
WARNING OPER.TIME	The programmed max. operating time for an OPEN - CLOSE operation has been exceeded
WARNING STARTS/RUN	The max. number of starts/h or max. running time/h has been exceeded.
LOCAL SW. POSITION	Selector switch in position LOCAL
REMOTE SW. POSITION	Selector switch in position REMOTE
OFF SW. POSITION	Selector switch in position OFF
REMOTE MODE	Operation mode REMOTE active
SETPOINT MODE	Operation mode SETPOINT MODE
INTERMED. POS. 1	Signalisation of the intermediate positions 1 to 4. Signal behaviour according to POS. 1 CONTROL to POS. 4 CONTROL parameters
INTERMED. POS. 2	
INTERMED. POS. 3	
INTERMED. POS. 4	
STEPPING MODE	Programmed stepping range (START STEP STOP STEP parameters) has been entered
CLOSING BLINK	Signal is blinking for operation in direction CLOSE. Signal is active in end position CLOSED.
OPENING BLINK	Signal is blinking for operation in direction OPEN. Signal is active in end position OPEN.
FAULT IND.	Collective signal includes: internal fault, torque fault, phase loss, thermal fault, and internal fault (refer to status indications on page 75)
WARNING IND.	Collective signal includes: operation time warning, warning starts/run, no reference operation, internal warnings, and signal losses (refer to status indications on page 75)
NOT READY IND.	Collective signal includes: remote ready selector switch not REMOTE, incorrect operation command, emergency operation (refer to status indications on page 76)
SETPOINT REACHED	Actuator is in nominal position
LOSS OF PHASE	One phase is missing
I/O1 ANALOG IN2 LOSS	Signal loss of the parallel interface analogue input 2
I/O1 ANALOG IN1 LOSS	Signal loss of the parallel interface analogue input 1


5.2.2 Configuration alarm contacts (collective fault signal): view/edit**Via the menu to parameter:**

MAIN MENU (M0)

SETTINGS (M1)

I/O 1 (M14)

ALARM CONTACT (M1411)



Default value: FAULT GROUP 3

Information

Faults interrupt or prevent the electrical operation of the actuator.

**Description of the parameter settings:**

Table 9 shows the value selection available for the fault signals:


Table 9	
Value	Signals (collective fault signal)
FAULT GROUP 1	– FAULT IND. – NOT READY IND.
FAULT GROUP 2	– FAULT IND. without torque fault – NOT READY IND.
FAULT GROUP 3	– FAULT IND.
FAULT GROUP 4	– FAULT IND. without torque fault
FAULT GROUP 5	– FAULT IND. – NOT READY IND. – WARNING IND.
FAULT GROUP 6	– FAULT IND. without thermal fault – NOT READY IND.
FAULT GROUP 7	– FAULT IND. without both torque and thermal faults – NOT READY IND.
FAULT GROUP 8	– FAULT IND. without thermal fault
FAULT GROUP 9	– FAULT IND. without both torque and thermal faults
FAULT GROUP 10	– FAULT without thermal fault – NOT READY IND. – WARNING IND.

5.2.3 Output contacts 1 to 5: use as running indication (blinker)



Via the menu to parameter:

```
MAIN MENU (M0)
  SETTINGS (M1)
    I/O 1 (M14)
      OUTPUT CONTACT 1 (M1412)
      OUTPUT CONTACT 2 (M1413)
      OUTPUT CONTACT 3 (M1414)
      OUTPUT CONTACT 4 (M1415)
      OUTPUT CONTACT 5 (M1416)
```



Description of the parameter settings:

CLOSING BLINK

Signal is active in end position CLOSED.
Signal is blinking for operation in direction CLOSE (depending on the BLINKER parameter).

OPENING BLINK

Signal is active in end position OPEN.
Signal is blinking for operation in direction OPEN (depending on the BLINKER parameter).

Information


The output contacts/LEDs of the local controls (page 19) can also be used to indicate whether the actuator is operated and if yes, in which direction.

Signal behaviour for BLINKER setting



Via the menu to parameter:

```
MAIN MENU (M0)
  SETTINGS (M1)
    LOCAL CONTROLS (M13)
      BLINKER (M1311)
```



Default value: OFF IN MIDPOSITION



Description of the parameter settings:

OFF

Signal is active in end position.
Blinker (running indication) is switched off.

LIT IN MIDPOSITION

Signal is active in end position and blinking during operation in direction of the end position. The signal remains active in intermediate position.

OFF IN MIDPOSITION

Signal is active in end position and blinking during operation in direction of the end position. The signal is off in intermediate position.

Information

The BLINKER parameter also influences the blinking behaviour of the indication lights/LEDs on the local controls.

5.3 Feedback signals (analogue) - (option)

These feedback signals are only available if a parallel interface is available in addition to the fieldbus interface (refer to page 66).
Depending on the actuator equipment, different signals can be recorded and issued as continuous values, e.g. 4 to 20 mA.

Table of contents:

5.3.1	Position transmitter/actual position source (E2): view
5.3.2	Source of the torque signal E6: view
5.3.3	Feedback signals via analogue output 1: view
5.3.4	Signal range at the analogue output 1: view/edit
5.3.5	Feedback signals via analogue output 2: view
5.3.6	Signal range at the analogue output 2: view/edit

5.3.1 Position transmitter/actual position source (E2): view


The valve position can be transmitted as a continuous signal by various position transmitters: The type of position transmitter/actual position source (E2) installed in the actuator is indicated here.
This value is set in the factory and can only be changed by the AUMA service.



Via the menu to parameter:

```

MAIN MENU (M0)
  CONFIGURATION (M4)
    SETUP (M41)
      FEEDBACK E2 (M4101)
  
```



Default value: POTENTIOMETER (for Non-Intrusive: MWG)

The following actual position sources (E2) are available:



Description of the parameter settings:

NONE

There is no position transmitter available in the actuator.

POT.

There is a potentiometer installed in the actuator.

0–20mA

There is an RWG installed in the actuator. The position feedback signal amounts to 0 – 20 mA.

4–20mA

There is an RWG installed in the actuator. The position feedback signal amounts to 4 – 20 mA.

MWG

There is an MWG (magnetic limit and torque transmitter) installed in the actuator.


5.3.2 Source of the torque signal E6: view

This value is set in the factory and can only be changed by the AUMA service.



Via the menu to parameter:

MAIN MENU (M0)
CONFIGURATION (M4)
SETUP (M41)
TORQUE E6 (M4103)



Default value: depending on actuator



Description of the parameter settings:

NONE

There is no electronic torque monitoring available.

LOGIC ANALOG IN1

The torque signal is transmitted from an external sensor via the logic board to the analogue input 1.

MWG

The torque signal is generated using the MWG installed in the actuator.

5.3.3 Feedback signals (configuration) via analogue output 1: view

Configuration of analogue output 1 (of the I/O).


Designation in the wiring diagram: ANOUT1.

This value is set in the factory and can only be changed by the AUMA service.



Via the menu to parameter:

MAIN MENU (M0)
CONFIGURATION (M4)
SETUP (M41)
I/O1 ANALOG OUT1 (M410A)



Default value: POSITION E2



Description of the parameter settings:

NOT USED

Analogue output 1 not used.

FEEDBACK E2:

Position feedback (analogue output 1 assigned to actual position signal).


If the actuator is equipped with a position transmitter (potentiometer, RWG or MWG), an analogue position feedback (galvanically isolated) is available as a 0/4 – 20 mA signal at the electrical connection (see wiring diagram). An adjustment to the end positions or the defined travel is not required. An automatic adjustment is done via the end positions (LSC (WSR) and LSO (WOEL)).

For torque seating, the end positions OPEN and CLOSED of the limit switching should be set as close as possible to the end positions of the valve to minimise the deviation of the feedback.

TORQUE E6

Analogue torque feedback signal (analogue output 1 assigned to torque signal). If a magnetic limit and torque transmitter (MWG) is installed, an analogue torque feedback (galvanically isolated) is available as a 0/4 – 20 mA signal at the electrical connection (refer to wiring diagram). The zero point is in the centre of the selected output range (at 10 mA or 12 mA). The torque in direction CLOSE is indicated with 0 – 10 mA or 4 – 12 mA, the torque in direction OPEN with 10 – 20 mA or 12 – 20 mA. For 100 % of the nominal output torque, 0 or 4 mA is indicated in direction CLOSE, and 20 mA is indicated in direction OPEN.

Figure 7



5.3.4 Signal range at the analogue output 1: view/edit

Signal range at the analogue output 1 (of the I/O).
This value must correspond to the desired feedback signal.



Via the menu to parameter:

```
MAIN MENU (M0)
  CONFIGURATION (M4)
    SETUP (M41)
      I/O1 ANALOG OUT1 TYPE (M411B)
```

EDIT	M411B
I/O1 ANALOG OUT1 TYP	
0-20mA	
⬆:EDIT	⬇:OK C:ESC

Default value: 0-20mA



Description of the parameter settings:

0-20mA

Analogue output 1 generates a 0 – 20 mA signal.

4-20mA

Analogue output 1 generates a 4 – 20 mA signal.

20-0mA

Analogue output 1 generates a 20 – 0 mA signal.

20-4mA

Analogue output 1 generates a 20 – 4 mA signal.

5.3.5 Feedback signals (configuration) via analogue output 2: view

Configuration of analogue output 2 (of the I/O).


Designation in the wiring diagram: ANOUT2.

This value is set in the factory and can only be changed by the AUMA service.



Via the menu to parameter:

MAIN MENU (M0)
CONFIGURATION (M4)
SETUP (M41)
I/O1 ANALOG OUT2 (M410C)



Default value: TORQUE E6



Description of the parameter settings:

NOT USED

Analogue output 2 not used.

FEEDBACK E2 :

Position feedback (analogue output 2 assigned to actual position signal).

Description see analogue output 1.

TORQUE E6

Analogue torque feedback signal (analogue output 2 assigned to torque signal). Description see analogue output 1.

5.3.6 Signal range at the analogue output 2: view/edit


Signal range at the analogue output 2 (of the I/O).

This value must correspond to the desired feedback signal.



Via the menu to parameter:

MAIN MENU (M0)
CONFIGURATION (M4)
SETUP (M41)
I/O1 ANALOG OUT2 TYPE (M411D)



Default value: 0-20mA



Description of the parameter settings:

0-20mA

Analogue output 2 generates a 0 – 20 mA signal.

4-20mA

Analogue output 2 generates a 4 – 20 mA signal.

20-0mA

Analogue output 2 generates a 20 – 0 mA signal.

20-4mA

Analogue output 2 generates a 20 – 4 mA signal.

6 Operation mode

Different operation modes (operation types) are available:
The current operation mode is indicated in the first line of the display:




Table of contents and short description of the operation modes (operation types):


- | | |
|-----|---|
| 6.1 | Operation mode OFF
No local control, no remote control possible. |
| 6.2 | Operation mode LOCAL
Control via push buttons OPEN, STOP, CLOSE at the local controls. |
| 6.3 | Operation mode REMOTE
Control by commands OPEN-STOP-CLOSE from remote control room or process control system. |
| 6.4 | Operation mode EMERGENCY
Control by command EMERGENCY from control room or process control system. |
| 6.5 | Operation mode FAILURE
Actuator behaviour on loss of signal. |

Further information in other clauses:


- | | |
|-----|---|
| 7.6 | Positioner (operation mode SETPOINT MODE)
Control via analogue setpoint, e.g. 0 - 20 mA. |
| 7.8 | Operation mode RESTRICTED
Operation via the local controls of the AUMATIC is disabled. |
| 7.9 | Operation mode EMERGENCY STOP
In combination with the EMERGENCY STOP button. |

6.1 Operation mode OFF

→ Set selector switch to position **0** (OFF).




Display indicates:




- No local control possible.
- No remote control possible.
- No EMERGENCY operation possible.
- The controls remain fully operative as far as signalling is concerned (controls' power supply is maintained).
- The ▲, ▼, ←, C push buttons can be used to set parameters and indications via the display.

6.2 Operation mode LOCAL

→ Set selector switch to position **Local control (LOCAL)**.



Display indicates:




- The actuator can be controlled via OPEN - STOP - CLOSE push buttons of the local controls.
- Faults and warnings without automatic reset can be confirmed with the **Reset** push button.

6.2.1 Push-to-run operation or self-retaining: set for the operation mode LOCAL



Via the menu to parameter:

MAIN MENU (M0)
SETTINGS (M1)
LOCAL CONTROLS (M13)
MAINTAINED LOCAL (M1310)



Default value: OPEN + CLOSE (STOP)



Description of the parameter settings:

OFF

Push-to-run operation off, self-retaining activated:
Actuator runs in direction OPEN or CLOSE after an operation command has been issued. If the operation command is removed, the actuator continues to run (self-retaining) until it is stopped by the STOP command or an end position or intermediate position has been reached.

OPEN

Push-to-run operation in direction OPEN activated:
Actuator only runs in direction OPEN while an operation command is issued. If the operation command is removed, the actuator stops.

CLOSE

Push-to-run operation in direction CLOSE activated:
Actuator only runs in direction CLOSE while an operation command is issued. If the operation command is removed, the actuator stops.

OPEN + CLOSE (STOP)


Push-to-run operation in direction OPEN and CLOSE activated:
Actuator only runs in direction OPEN or CLOSE while an operation command is issued. If the operation command is removed, the actuator stops.

OPEN+CLOSE (NO STOP)


Self-retaining without STOP:
A direct reversal of the direction of rotation without STOP command is possible.

6.3 Operation mode REMOTE

→ Set selector switch to position **Remote control** (REMOTE).



Display indicates:



The actuator is controlled by external REMOTE commands OPEN - STOP - CLOSE.

Information If SETPOINT MODE is displayed, a positioner (option) is available. In this case, selection can be made between REMOTE MODE and SETPOINT MODE (refer to page 53).

6.3.1 Push-to-run operation or self-retaining: set for operation mode REMOTE


The parameter has no influence on the operation commands transmitted via fieldbus.

Setting is only required if a further parallel interface is available in addition to the fieldbus interface (refer to page 66).



Via the menu to parameter:

```
MAIN MENU (M0)
  SETTINGS (M1)
    I/O 1 (M14)
      MAINTAINED REMOTE (M1410)
```



Default value: OFF



Description of the parameter settings:

OFF

Push-to-run operation off, self-retaining activated:

Actuator runs in direction OPEN or CLOSE after an operation command has been issued. If the operation command is removed, the actuator continues to run (self-retaining) until it is stopped by the STOP command or an end position or intermediate position has been reached.

OPEN

Push-to-run operation in direction OPEN activated:

Actuator only runs in direction OPEN while an operation command is issued. If the operation command is removed, the actuator stops.

CLOSE

Push-to-run operation in direction CLOSE activated:

Actuator only runs in direction CLOSE while an operation command is issued. If the operation command is removed, the actuator stops.

OPEN + CLOSE (STOP)

Push-to-run operation in direction OPEN and CLOSE activated:

Actuator only runs in direction OPEN or CLOSE while an operation command is issued. If the operation command is removed, the actuator stops.

OPEN+CLOSE (NO STOP)
Self-retaining without STOP:
A direct reversal of the direction of rotation without STOP command is possible.

6.4 Operation mode EMERGENCY

In an emergency, the actuator can be brought to a programmed EMERGENCY position by removing the EMERGENCY signal.
As the EMERGENCY signal works active low, 24 V DC must be present at the EMERGENCY input while in the normal state (refer to wiring diagram). An EMERGENCY operation is performed when the signal is interrupted (0 V). During EMERGENCY operation the actuator does not perform any operation commands.
After initiating an EMERGENCY operation (the EMERGENCY input is again supplied with 24 V DC), the operation commands must be deleted and have to be reapplied. This does not apply to operation commands being transferred via the 0/4 – 20 mA input or via fieldbus telegrams. They will immediately be executed again.


Information For actuators equipped with a fieldbus interface, the EMERGENCY operation behaviour is only available if an I/O interface (fieldbus standard combination, page 66) or additional control inputs (page 63) are available.

Table of contents:

6.4.1	Operation mode (type of duty) activation for an EMERGENCY operation
6.4.2	EMERGENCY operation: switch on or off/signal behaviour definition
6.4.3	Actuator behaviour definition in case of an emergency operation
6.4.4	EMERGENCY position definition
6.4.5	Motor protection and/or torque switching by-pass

6.4.1 Operation mode (type of duty) activation for an emergency operation

- ➡ **Via the menu to parameter:**
MAIN MENU (M0)
 SETTINGS (M1)
 EMERGENCY BEHAVIOUR (M16)
 EMERG.SEL.SW.POS. (M1612)



Default value: REMOTE ONLY

Description of the parameter settings:

REMOTE ONLY
Emergency operation only possible in selector switch position REMOTE


REMOTE AND LOCAL
Emergency operation possible in selector switch position REMOTE and LOCAL

Information

- The operation mode EMERGENCY has the highest priority.
- No emergency operation is performed when the selector switch is in position OFF.

6.4.2 EMERGENCY operation: switch on or off/signal behaviour definition**Via the menu to parameter:**

MAIN MENU (M0)
 SETTINGS (M1)
 EMERGENCY BEHAVIOUR (M16)
 EMERGENCY BEHAVIOUR (M1610)



Default value: OFF

**Description of the parameter settings:****OFF**

Emergency operation is switched off.

GOOD SIGNAL FIRST

An EMERGENCY operation is only triggered when the EMERGENCY signal at the EMERGENCY input drops from 24 V to 0 V, i.e. provided that a 24 V signal was previously connected to the EMERGENCY input.

ACTIVE IMMEDIATE


An EMERGENCY operation is only initiated if 0 V are connected to the EMERGENCY signal input.

Information

For **ACTIVE IMMEDIATE**, an EMERGENCY operation is initiated immediately after the actuator is switched on, when 0 V are connected to the EMERGENCY signal input.

6.4.3 Actuator behaviour definition in case of an emergency operation**Via the menu to parameter:**

MAIN MENU (M0)
 SETTINGS (M1)
 EMERGENCY BEHAVIOUR (M16)
 EMERGENCY POSITION (M1611)



Default value: FAIL AS IS

**Description of the parameter settings:****FAIL AS IS**

The actuator stops in the current position.

FAIL CLOSE

The actuator runs to end position CLOSED.

FAIL OPEN

The actuator runs to end position OPEN.

FAIL TO PRESET

The actuator runs to the predetermined position.


6.4.4 EMERGENCY position definition

If the EMERGENCY operation action FAIL TO PRESET (EMERGENCY POSITION parameter) is set, the actuator runs to the EMERGENCY position stated here.



Via the menu to parameter:

MAIN MENU (M0)
 SETTINGS (M1)
 EMERGENCY BEHAVIOUR (M16)
 PRESET POSITION (M1614)



Default value: 0.0 %
Setting range: from 0.0 % to 100.0 % (from OPEN to CLOSED)


6.4.5 Motor protection and/or torque switching: by-pass

During the EMERGENCY operation, the motor protection and/or torque switching can be by-passed. This value is set in the factory and can only be changed by the authorised AUMA staff.



Via the menu to parameter:

MAIN MENU (M0)
 SETTINGS (M1)
 EMERGENCY BEHAVIOUR (M16)
 EMERGENCY BY-PASS (M1603)



Default value: NONE



Description of the parameter settings:

NONE

No by-pass of motor protection

THERMAL

The signals of the thermoswitches or the PTC thermistors of the motor winding are by-passed.

TORQUE

The signals of the torque switching in the actuator (TSC (DSR)/TSO (DOEL)) are by-passed

THERMAL AND TORQUE

The signals of the thermoswitches or PTC thermistors and the signals of the torque switching are by-passed.

Information

For actuators with explosion protection, the motor protection and the torque switching cannot be by-passed.

6.5 Fault State behaviour in case of bus communication loss

The fault state behaviour of the Foundation Fieldbus function blocks (AOFB or DOFB) have to be configured to activate the failure behaviour in case of Foundation Fieldbus communication loss.


The fault state behaviour is configured via Foundation Fieldbus by means of a configuration software.

For further information, please refer to “Manual (Device integration Fieldbus) AUMATIC AC 01.1/ACExC 01.1 Foundation Fieldbus”.

6.6 Failure behaviour in case of analogue signal loss (option)

The operation mode FAILURE enables an initiation of failure operations in case of signal loss of an analogue 4 – 20 mA setpoint signal.

If the FAILURE mode is enabled, the display indicates:



Conditions:

- in addition to the Foundation Fieldbus interface, the AUMATIC is equipped with a further parallel interface (refer to page 66).
- the AUMATIC is equipped with additional control inputs (refer to page 63).

Failure behaviour: switch on or off




Via the menu to parameter:

MAIN MENU (M0)

SETTINGS (M1)

FAILURE BEHAVIOUR (M15)

FAILURE BEHAVIOUR (M1510)



Default value: OFF

Description of the parameter settings:

OFF

Failure behaviour is switched off.

GOOD SIGNAL FIRST

A failure operation is only initiated when no wire break is recognised after switching on, but wire break is recognised later through loss of signal. With this setting, it is ensured that the actuator does not perform a preset failure action (failure position) when switched on without signal E1 connected.

FAIL IMMEDIATE

A failure operation is initiated in case of cable break.


Information If FAIL IMMEDIATE is switched on, a failure operation is initiated immediately after the actuator is switched on if a loss of signal has occurred.

Source for initiation (failure source): set for failure operation



Via the menu to parameter:

MAIN MENU (M0)
SETTINGS (M1)
FAILURE BEHAVIOUR (M15)
FAILURE SOURCE (M1514)



Default value: SETPOINT E1

Information Recommended setting: SETPOINT E1



Description of the parameter settings:

SETPOINT E1

Failure behaviour is initiated if setpoint E1 fails.

The monitoring depends on the preset setpoint range, e.g.:

E1 = 4 – 20 mA, E1 lower than 3,7 mA = loss of signal

E1 = 10 – 20 mA, E1 lower than 9.7 mA = loss of signal

Monitoring of E1 = 0 – 20 mA is not possible

E1 OR E2 FEEDBACK

Failure behaviour is initiated if setpoint E1 or feedback E2 fail.

The following is monitored:

- for actuators with potentiometer: Cable break is detected
- for electronic position transmitter RWG 4 – 20 mA in actuator:
E2 lower than 3.7 mA = signal loss
- for MWG in actuator:
Communication faults and MWG internal faults are recognised

E1, E2 OR E4 FEEDBACK


Failure behaviour is initiated if setpoint E1, feedback E2, or process variable E4 fail.

Actuator reaction (failure position): setting on loss of signal



Via the menu to parameter:

MAIN MENU (M0)
SETTINGS (M1)
FAILURE BEHAVIOUR (M15)
FAILURE POSITION (M1512)



Standard value: FAIL AS IS

Description of the parameter settings:

FAIL AS IS

The actuator stops in the current position.

FAIL CLOSE

The actuator runs to end position CLOSED.

FAIL OPEN

The actuator runs to end position OPEN

FAIL TO PRESET

The actuator runs to a predetermined position.

Preset position definition

If the FAIL TO PRESET failure action (FAILURE POSITION parameter) is set, the actuator runs to the preset position stated here.

**Via the menu to parameter:**

MAIN MENU (M0)

SETTINGS (M1)

FAILURE BEHAVIOUR (M15)

PRESET POSITION (M1513)

```

EDIT                M1513
PRESET POSITION
0.0 %
⬆:EDIT  ⬇:OK  C:ESC
  
```

Standard value: 0.0 %

Setting range: from 0.0 % to 100.0 % (from OPEN to CLOSED)

Failure delay time setting

Determines the time elapsed between the recognition of a cable break and the initiation of the failure action.

**Via the menu to parameter:**

MAIN MENU (M0)

SETTINGS (M1)

FAILURE BEHAVIOUR (M15)

DELAY TIME (M1511)

```

EDIT                M1511
DELAY TIME
3.0 s
⬆:EDIT  ⬇:OK  C:ESC
  
```

Default value: 3.0 s

Setting range: 0.0 to 1200.0 seconds (20 minutes)

7

Functions

7.1

Type of seating: check/edit end positions

NOTICE

Valve damage due to incorrect setting!
→ The torque must suit the valve.
→ Only change the setting with the consent of the valve manufacturer.

Limit seating

The limit switching is set in such a way that the actuator switches off at the desired switching points. The torque switching acts as an overload protection for the valve.

Torque seating

The torque switching is set to the desired tripping torque. After reaching the tripping torque the actuator is turned off.
The limit seating needs to be set in such a way that the limit switching is tripped shortly before reaching the set tripping torque. If this is not the case, one of the following fault signals is displayed: TSO FAULTS or TSC FAULTS (menu S1).

- ➡
- Via the menu to parameter:**
MAIN MENU (M0)
 SETTINGS (M1)
 SEATING MODE (M11)
 OPEN POSITION (M1110)
 CLOSED POSITION (M1111)

EDITM1110
OPEN POSITION
LIMIT
⬆:EDIT ⬇:OK C:ESC

EDITM1111
CLOSED POSITION
LIMIT
⬆:EDIT ⬇:OK C:ESC

Default value: LIMIT

7.2 Torque switching: check/set

This setting is only possible for the non-intrusive version.
For further information refer to page 8.

NOTICE

Valve damage due to incorrect setting!



- The torque must suit the valve.
- Only change the setting with the consent of the valve manufacturer.



Via the menu to parameter:

```

MAIN MENU (M0)
  SETTINGS (M1)
    TORQUE (M12)
      OPENING (M1210)
      CLOSING (M1211)
  
```



Default value: according to order data
Setting range: according to torque setting range
refer to actuator name plate

Information

The value can be displayed in percent, Newtonmeter (Nm), or in Lbs/ft.
To change the display unit, refer to page 16.
To display in percent:
100 % equals the max. torque indicated on the name plate of the actuator.
Example: SA 07.5 with 20 – 60 Nm: 100 % = 60 Nm
33 % = 20 Nm

Information

The following fault signals are sent if torque setting performed has been reached **in mid-travel**:

- Status indication S0: operation mode OFF/LOCAL = FLT + NR
- Status indication S0/S6: operation mode REMOTE = FAULT IND.
- Status indication S1: TORQUE FAULT (OPEN) or TORQUE FAULT (CLOSE) (torque fault)
- The Foundation Fieldbus APVB transducer block signals a fault via XD_ERROR (General Error, 17 (0x11)) and XD_ERROR_EXT (Torque fault OPEN, 0x00000001 or Torque fault CLOSE, 0x00000002), thus generating an operation mode change of the DOFB or AOFB to the IMan status.

The fault has to be acknowledged before the operation can be resumed.
The acknowledgement is made:



1. either by an operation command in the opposite direction.
 - For TORQUE FAULT (CLOSE): Operation command in direction OPEN
 - For TORQUE FAULT (OPEN): Operation command in direction CLOSE
2. or, in case the torque present is smaller than the preset tripping torque:
 - via the **Reset** push button in selector switch position LOCAL.
 - via the APPLICATION_RESET Foundation Fieldbus parameter of the APVB transducer block (index 784).

7.3 Limit switching setting

This setting is only possible for the non-intrusive version
For further information refer to page 8.



Via the menu to parameter:
MAIN MENU (M0)
 SETTINGS (M1)
 SET LIMIT SWITCHES (M10)
 CLOSED POSITION (M100)
 OPEN POSITION (M101)



Information For end position setting, turn selector switch to LOCAL position and move the actuator into the end position, either via manual or motor operation (using the push buttons). Then turn the selector switch back to position OFF and accept end position.

NOTICE

Valve damage due to direct approaching of mechanical end stop during motor operation!
→ During motor operation, interrupt travel before reaching the mechanical valve end stop (press push button STOP).

Information If an end position cannot be set:
→ Check the type of control unit in actuator.

7.4 Intermediate positions (option)

The AUMATIC allows to define up to 8 intermediate positions.

Condition

The actuator is either equipped with:

- an MWG (for Non-Intrusive version), or
- a potentiometer (5 kΩ) or
- an RWG

In these versions, the positioning of the intermediate positions is made via software parameters.

Selection of the intermediate positions can be made either via push buttons from LOCAL or via the fieldbus interface from REMOTE with the standard commands OPEN and CLOSE. The actuator stops when reaching the intermediate position. The operation command has to be cleared and sent again to resume operation to the next intermediate position.

Information

If the intermediate positions are to be approached directly (without stop), the multiport valve function (page 47) is available as an option.

Table of contents:

7.4.1	Display indication: enable view
7.4.2	Intermediate positions: switch on or off
7.4.3	Intermediate position definition
7.4.4	Operation behaviour = actuator behaviour definition
7.4.5	Intermediate positions: set the signalling


7.4.1 Display indication: enable view

The INTERMED. POSITION parameter must be set to VIEW ENABLED to carry out settings in the intermediate positions.



Via the menu to parameter:

```
MAIN MENU (M0)
  CONFIGURATION (M4)
    SPECIAL FUNCTIONS (M40)
      INTERMED. POSITION (M4015)
```



Default value: VIEW NOT ENABLED

Description of the parameter settings:

VIEW NOT ENABLED

The parameter for the intermediate positions are not indicated in the display.

VIEW ENABLED

The parameter for the intermediate positions are indicated in the display.

7.4.2 Intermediate positions: switch on or off

Each intermediate position (POS.1 to POS8.) may individually be switched on/off.



Via the menu to parameter:

```
MAIN MENU (M0)
  SETTINGS (M1)
    INTERMED. POSITION (M1C)
      POS.1 SELECTOR SW. (M1C12)
```

```

EDIT                               M1C12
POS.1 SELECTOR SW
OFF
⬆:EDIT  ⬇:OK  C:ESC
```

Default value: OFF



Description of the parameter settings:

OFF

Intermediate position switched off.

REMOTE ONLY

Intermediate position only active in operation mode REMOTE.

LOCAL ONLY

Intermediate position only active in operation mode LOCAL.

REMOTE AND LOCAL

Intermediate position active in operation modes REMOTE and LOCAL.

7.4.3 Intermediate position definition

Each intermediate position (POS.1 to POS.8) can be set to any value between 0 % and 100 % of the travel.

This function is only available the with position feedback.



Via the menu to parameter:

```
MAIN MENU (M0)
  SETTINGS (M1)
    INTERMED. POSITION (M1C)
      POS.1 (M1C10)
```

```

EDIT                               M1C10
POS.1
0.0 %
⬆:EDIT  ⬇:OK  C:ESC
```

Default value: 0,0 %


Setting range: 0.0 % to 100.0 % of the travel
(from OPEN to CLOSED)

7.4.4 Operation behaviour = actuator behaviour definition

The reaction of the actuator upon reaching an intermediate position can be programmed via the parameters "POS. 1: BEHAVIOUR to POS. 8: BEHAVIOUR.

**Via the menu to parameter:**

```
MAIN MENU (M0)
  SETTINGS (M1)
    INTERMED. POSITION (M1C)
      POS.1 BEHAVIOUR (M1C11)
```



Default value: NO STOP

**Description of the parameter settings:****NO STOP**

No intermediate stop, actuator continues the operation.

STOP OPENING DIR.

Actuator stops during operation in direction OPEN upon having reached the intermediate position. Actuator only runs after a new operation command is issued.

This function is not active in the operation mode SETPOINT MODE.

STOP CLOSING DIR.

Actuator stops during operation in direction CLOSE after reaching the intermediate position. Actuator only runs after a new operation command is issued.

This function is not active in the operation mode SETPOINT MODE.

STOP BOTH DIR.

Actuator stops after reaching the intermediate position. Actuator only runs after a new operation command is issued.

This function is not active in the operation mode SETPOINT MODE.

7.4.5 Intermediate positions: set the signalling


The reaching of an intermediate position can be signalled:

- via bus (see separate operation instructions)
- via the indication lights (LEDs) of the local controls (page 19) or
- via the output contacts (page 23)

The signal behaviour of the individual intermediate positions is set via the POS. 1–8 control parameters:

**Via the menu to parameter:**

```
MAIN MENU (M0)
  SETTINGS (M1)
    INTERMED. POSITION (M1C)
      POS.1 CONTROL (M1C13)
```




Default value: NOT USED

↓ **Description of the parameter settings:**

- NOT USED**
No signal.
- C _ _ _ POS _ _ _ O**
Signal active from reaching the intermediate position to end position OPEN.
- C _ _ _ POS _ _ _ O**
Signal active from end position CLOSED to reaching the intermediate position.
- C _ _ _ POS _ _ _ O**
Impulse signal issued when going through intermediate position

Figure 8 shows the signal behaviour in intermediate positions.



Further feedback signals which can be used together with the multiport valve function (option):

Description of the parameter settings:

- SETPOINT REACHED**
As each intermediate position is processed as a setpoint, the signal SETPOINT REACHED is issued after reaching any intermediate position.
- ACTUATOR MOVING**
Is signalled as long as the actuator is still running to the intermediate position and no intermediate position signal has been issued yet.

7.5 Intermediate positions with multiport valve function (option)

The multiport valve function allows the selection of the eight intermediate positions either directly from LOCAL (via push buttons) or from REMOTE (via special fieldbus commands). **Hereby the selected intermediate position is approached directly, without stopping in another intermediate position.**

Limitation

In this case, the actuator continues running until the selected intermediate position has been reached. Example: Operation from position 5 to 7 without stopping at position 6. This function is available with operation commands from LOCAL via the push buttons or from REMOTE via a fieldbus interface. When equipped with a parallel interface (page 66), the direct selection function is only available in local operation, since the number of control cables is not sufficient to select a specific intermediate position.

Table of contents:

7.5.1	Check: Multiport valve function available?
7.5.2	Check: Positioner active?
7.5.3	Display indication: enable view
7.5.4	Intermediate positions: switch on or off
7.5.5	Intermediate position setting
7.5.6	Operation behaviour = actuator behaviour definition
7.5.7	Intermediate positions signalling
7.5.8	Intermediate positions in LOCAL: direct approach without stopping


7.5.1 Check: Multiport valve function available?

The multiport valve is available if the POS. DIRECTRUNNING (M400B) parameter is displayed in the SPECIAL FUNCTIONS (M40) menu.

**Via the menu to parameter:**

```

MAIN MENU (M0)
  CONFIGURATION (M4)
    SPECIAL FUNCTIONS (M40)
      POS. DIRECTRUNNING (M400B)
  
```



Default value: FUNCTION NOT ACTIVE

**Description of the parameter settings:****FUNCTION NOT ACTIVE**

Multiport valve function off = selection of the respective subsequent intermediate position via OPEN - CLOSE commands

FUNCTION ACTIVE

Multiport valve function on = direct selection of intermediate positions possible from both REMOTE and LOCAL.


Information

The function is either activated or deactivated via the EDIT menu. This value is set in the factory and can only be changed by the AUMA service.

7.5.2 Check: Positioner active?

The positioner must be available. This value is set in the factory.

- ➡
- Via the menu to parameter:**
MAIN MENU (M0)
 CONFIGURATION (M4)
 SPECIAL FUNCTIONS (M40)
 POSITIONER (M4000)



The POSITIONER parameter must be set to POSITIONER ENABLED.

- ↓
- Description of the parameter settings:**
FUNCTION NOT ACTIVE
There is no positioner available.
POSITIONER ENABLED
The controls are equipped with a positioner.

7.5.3 Display indication: enable view

The indication of the multiport valve intermediate positions in the display is performed as described on page 17.


7.5.4 Intermediate positions: switch on or off

The multiport valve intermediate positions are switched on/off as described on page 44.

7.5.5 Intermediate position setting

Each of the 8 intermediate positions must be programmed. For direct selection of the intermediate positions from either LOCAL or REMOTE, it is sufficient to define the position (POS. 1–8) parameter of each intermediate position.

- ➡
- Via the menu to parameter:**
MAIN MENU
 SETTINGS (M1)
 INTERMED. POSITION (M1C)
 POS.1 (M1C10)



Setting ranges: 0.0 % to 100.0 % of the travel (from OPEN to CLOSED)
Typically all 8 outputs of the valve are distributed evenly over 360°, therefore the limit switch CLOSE should be set to output 1 and the limit switch OPEN to output 8. Afterwards the positions of the intermediate positions can be set:

Intermediate position 1:	POS.1	0.0 %	(output 1)
Intermediate position 2:	POS.2	14.3 %	(output 2)
Intermediate position 3:	POS.3	28.6 %	(output 3)
Intermediate position 4:	POS.4	42.9 %	(output 4)
Intermediate position 5:	POS.5	57.1 %	(output 5)
Intermediate position 6:	POS.6	71.4 %	(output 6)
Intermediate position 7:	POS.7	85.7 %	(output 7)
Intermediate position 8:	POS.8	100.0 %	(output 8)

7.5.6 Operation behaviour = actuator behaviour definition

The operation behaviour setting of the multiport valve intermediate positions is performed as described on page 45.

7.5.7 Intermediate positions signalling

The signalling of the multiport valve intermediate positions is performed as described on page 45.

Reaching an intermediate position can be signalled:

- via the bus (refer to separate manual)
- via the signal contacts (LEDs) of the local controls (page 19) or
- via the signal contacts (page 23)

In addition to the “intermediate position reached” signal, the following feedback signals can be used together with the multiport valve function:

SETPOINT REACHED

As each intermediate position is processed as a setpoint, the signal SETPOINT REACHED is issued after reaching any intermediate position.

ACTUATOR MOVING

Is signalled as long as the actuator is still running to the intermediate position and no intermediate position signal has been issued yet.

7.5.8 Intermediate positions in LOCAL: direct approach without stopping**Via the menu to parameter:**

MAIN MENU (M0)


RUNNING TO POS. (M5)

POS. NUMBER (M50)

Now enter desired intermediate position


- Set selector switch to position **Local control** (I).
Actuator runs to selected intermediate position

Indication on the display during operation:



- ← Line 1: operation mode
- ← Line 2: selected intermediate position
- ← Line 3: position feedback
- ← Line 4: status signal

Indication in display after having reached intermediate position:




- To approach a new intermediate position:
- Set selector switch to position **OFF** (0).
 - Enter desired intermediate position.
 - Set selector switch to position **Local control** (I).
- Actuator runs to desired intermediate position.

7.6 **Positioner (operation mode SETPOINT MODE)**

The positioner records position setpoint E1 and position feedback E2 for comparison. Depending on the detected deviation, the actuator motor then runs in direction OPEN or CLOSE.

- Set selector switch to position REMOTE.
If the positioner is active, the display shows:




Information If the display shows REMOTE MODE, the actuator is set to open-close duty and no modulation is performed. In this case, modulating duty has to be selected first, refer to page 53.

Table of contents:	
7.6.1	Adaptive behaviour: switch on or off
7.6.2	Overrun (inner dead band): manual setting
7.6.3	Max. error variable (outer dead band): manual setting
7.6.4	Dead time setting
7.6.5	Closing fully/opening fully (end position tolerance for setpoint E1)
7.6.6	Open-close and modulating duty selection
7.6.7	Source of setpoint E1: view
7.6.8	Input range of setpoint E1: view/edit

7.6.1 **Adaptive behaviour: switch on or off**

As standard, the adaptive positioning is switched on, i.e. overrun and max. error variable are automatically defined by the positioner (figure 9). If the setting is to be made manually, the ADAPTIVE BEHAVIOUR parameter must be in position OFF.


- ➡ **Via the menu to parameter:**
MAIN MENU (M0)
 CONFIGURATION (M4)
 SPECIAL FUNCTIONS (M40)
 ADAPTIVE BEHAVIOUR (M4011)



Default value: ON

- ↓ **Description of the parameter settings:**
OFF
Adaptive behaviour switched off.
ON
Adaptive behaviour switched on.

Figure 9 shows the modulating behaviour:



E1	Nominal value	T1	Outer dead band
E2	Actual value	T2	Max. error variable
P1	Switch-on point	T3	Inner dead band
P2	Switch-off point in direction OPEN	T4	Overrun
P3	Nominal value reached		

Information If the adaptive behaviour is switched off, overrun and max. error variable must be set manually (refer to subclauses 7.6.2 and 7.6.3).

7.6.2 Overrun (inner dead band): set manually

The inner dead band determines the switch-off point of the actuator and, therefore, influences the overrun (figure 9).

The inner dead band may be set individually for the directions OPEN and CLOSE.

Manual setting is only possible if the adaptive behaviour (ADAPTIVE BEHAVIOUR parameter) is switched off.



Via the menu to parameter:

MAIN MENU (M0)

SETTINGS (M1)

POSITIONER (M19)

OPENING DEADBAND (M1913)

CLOSING DEADBAND (M1914)

EDIT	M1913
OPENING DEADBAND	
0.5 %	
⬆:EDIT	⬆:OK C:ESC

EDIT	M1914
CLOSING DEADBAND	
0.5 %	
⬆:EDIT	⬆:OK C:ESC

Default values: OPENING DEADBAND = 0.5 %

CLOSING DEADBAND = 0.5 %

Setting ranges: OPENING DEADBAND = 0.0 % to 9.9 %


CLOSING DEADBAND = 0.0 % to 9.9 %

7.6.3 Max. error variable (outer dead band): set manually

The outer deadband determines the switching-on point of the actuator. The motor starts if the actual value (input signal E2) or a change in nominal value is higher than the max. error variable determined by the outer dead band (refer to figure 9). Manual setting is only possible if the adaptive behaviour (ADAPTIVE BEHAVIOUR parameter) is switched off.

- ➡
- Via the menu to parameter:**

MAIN MENU (M0)
 SETTINGS (M1)
 POSITIONER (M19)
 OUTER DEADBAND (M1915)




Default value: 1.0 %
Setting range: 0.1 % to 9.9 %

7.6.4 Dead time setting

The dead time prevents the operation to a new nominal position within a pre-determined time.

- ➡
- Via the menu to parameter:**

MAIN MENU (M0)
 SETTINGS (M1)
 POSITIONER (M19)
 DEAD TIME (M1910)



Default value: 0.5 s
Setting range: 0.0 to 60.0 seconds

Information

It must be ensured via the controls that the max. permissible number of starts of the actuator is not exceeded. This can be achieved by setting the dead time to a sufficiently high value.

7.6.5 Closing fully/opening fully (end position tolerance for setpoint E1)



If the end positions cannot be reached due to inaccurate analogue setpoint signals (0/4 mA or 20 mA), a tolerance for the nominal value within the end position range can be set. If the tolerance is exceeded or not reached, the actuator continues the operation until the full end position has been reached. This ensures that the actuator opens and closes fully.

Information The tolerance ranges are not effective if the operation commands are transferred to the actuator as fieldbus telegrams. In this case the actuator runs completely CLOSED as soon as it receives the nominal value 0 % and completely OPEN as soon as it receives the nominal value 100.0 %.



Via the menu to parameter:

```
MAIN MENU (M0)
  SETTINGS (M1)
    POSITIONER (M19)
      FULL OPEN ADJUST (M1911)
      FULL CLOSE ADJUST (M1912)
```



Default values: FULL OPEN ADJUST = 100 %

FULL CLOSE ADJUST = 0 %

Setting ranges: FULL OPEN ADJUST = 95 % to 100 % of travel

FULL CLOSE ADJUST = 0 % to 50 % of travel

7.6.6 Open-close duty (REMOTE) or modulating duty (SETPOINT) selection

Selection between open-close duty and modulating duty is defined by the appropriate function blocks:

Open-close duty: Use Discrete Output Function Block (DOFB).

Modulating duty: Use Analog Output Function Block (AOFB).

Information These two function blocks may not be used simultaneously.

The following versions also allow a change-over between open-close and modulating duty via the MODE input (refer to wiring diagram):

- in addition to the Foundation Fieldbus interface, the AUMATIC is equipped with a further parallel interface (refer to page 66)
- the AUMATIC is equipped with additional control inputs (refer to page 63).

MODE input: + 24 V DC = REMOTE MODE = open-close duty, i.e. the control is executed via commands OPEN - STOP - CLOSE

MODE input: 0 V (or input open) = SETPOINT = modulating duty, i.e. the control is executed via an analogue signal (e.g. 0/4 – 20 mA)


7.6.7 Source of setpoint E1: view

This value is set in the factory and can only be changed by the AUMA service.



Via the menu to parameter:

MAIN MENU (M0)
 CONFIGURATION (M4)
 SETUP (M41)
 SETPOINT E1 (M4100)



Default value: FOUNDATION FIELDBUS



Description of the parameter settings:

NONE

There is no setpoint source available.

LOGIC ANALOG IN1

For AUMA service only (the setpoint E1 is transmitted from external via the analogue input 1 directly to the logic board).

I/O1 ANALOG IN1

The setpoint E1 is transmitted via the I/O board interface, analogue input 1.

I/O1 ANALOG IN2

The setpoint E1 is transmitted via the I/O board interface, analogue input 2.

FOUNDATION FIELDBUS

The setpoint E1 is transmitted via the Foundation Fieldbus interface board.

FF ANALOG IN1

The setpoint E1 is transmitted via the Foundation Fieldbus interface board, analogue input 1.

FF ANALOG IN2

The setpoint E1 is transmitted via the Foundation Fieldbus interface board, analogue input 2.

7.6.8 Input range of setpoint 1: view/edit

The parameters of this setting depend on the pre-set setpoint source (SETPOINT E1 (M4100) parameter, page 54).

Initial and end value via the Foundation Fieldbus interface

In Foundation Fieldbus standard version, the setpoint E1 is transmitted via the AO function block.

Initial and end value via I/O interface

As an option, the setpoint E1 can be supplied via an analogue input instead of using the fieldbus. This is possible for the following versions:

- a) in addition to the Foundation Fieldbus interface, the AUMATIC is equipped with a further parallel interface (refer to page 66)
 - b) the AUMATIC is equipped with additional control inputs (refer to page 63)
- The input range amounts to 0/4 – 20 mA. It is possible to modify the input range via the display for both versions:

Version a) for setpoint source of parallel interface, analogue input 1:**Via the menu to parameter:**

```
MAIN MENU (M0)
  CONFIGURATION (M4)
    SETUP (M41)
      I/O ANLOG IN1 START (M410H)
      I/O ANLOG IN1 END (M410I)
```

VIEW
I/O1 ANLOG IN1 START
0.0 mA
C:ESC

VIEW
I/O1 ANLOG IN1 END
20 mA
C:ESC

Default values: I/O ANLOG IN1 START = 0 mA
I/O ANLOG IN1 END = 20 mA

Setting ranges: I/O ANLOG IN1 START = 0 to 20 mA
I/O ANLOG IN1 END = 0 to 20 mA

Version b) for setpoint source of Foundation Fieldbus interface, analogue input 1:**Via the menu to parameter:**

```
MAIN MENU (M0)
  SETTINGS (M1)
    FF-INTERFACE 1 (M1M)
      FF ANLOG IN1 START (M1M00)
      FF ANLOG IN1 END (M1M01)
```

VIEW
FF ANLOG IN1 START
0.0 mA
C:ESC

VIEW
FF ANLOG IN1 END
20.0 mA
C:ESC

Default values: FF ANLOG IN1 START = 0 mA
FF ANLOG IN1 END = 20 mA


Setting ranges: FF ANLOG IN1 START = 0 to 20 mA
FF ANLOG IN1 END = 0 to 20 mA

Information

If the measuring values are 0.3 mA below the initial value a wire break is indicated as a warning.

7.7 Stepping mode (option)

In stepping mode the operating time can be increased for the entire or any portion of the valve travel (refer to figure 10).



Information Stepping mode is only possible if a position transmitter (potentiometer, RWG, or MWG) is installed in the actuator.

Table of contents:

7.7.1	Display indication: enable view
7.7.2	Stepping mode: switch on or off
7.7.3	Stepping range setting (start and end of stepping mode).
	ON and OFF times setting


7.7.1 Display indication: enable view

To perform settings for stepping mode via the display, the STEPPING MODE setting must be in position VIEW ENABLED.



Via the menu to parameter:

MAIN MENU (M0)
CONFIGURATION (M4)
SPECIAL FUNCTIONS (M40)
STEPPING MODE (M4014)



Default value: VIEW NOT ENABLED



Description of the parameter settings:

VIEW NOT ENABLED

The parameters for the stepping mode are not indicated in the display.

VIEW ENABLED


The parameters for the stepping mode are indicated in the display.

7.7.2 Stepping mode: switch on or off

Stepping mode can be individually activated for the directions OPEN and CLOSE.

**Via the menu to parameter:**

```
MAIN MENU (M0)
  SETTINGS (M1)
    STEPPING MODE (M17)
      DIRECTION OPEN (M170)
      DIRECTION CLOSE (M1715)
```



Default values: DIRECTION OPEN = OFF
DIRECTION CLOSE = OFF

**Description of the parameter settings:****OFF**

Stepping mode is switched off

REMOTE ONLY

Stepping mode only possible in operation mode REMOTE.

LOCAL ONLY

Stepping mode only possible in operation mode LOCAL.

REMOTE AND LOCAL



Stepping mode in operation modes REMOTE and LOCAL possible

7.7.3 Stepping range setting (start and end of stepping mode).

For both directions the stepping range (start and end of stepping mode) can be set separately.

**Via the menu to parameter:**

```
MAIN MENU (M0)
  SETTINGS (M1)
    STEPPING MODE (M17)
      START STEP OPEN (M1713)
      STOP STEP OPEN (M1714)
      START STEP CLOSE (M1718)
      STOP STEP CLOSE (M1719)
```



Default values: START STOP OPEN = 0.0 %
STOP STEP OPEN = 100.0 %
START STEP CLOSE = 100.0 %
STOP STEP CLOSE = 0.0 %

Setting ranges: START STEP OPEN = 0.0 % to 99.9 %
STOP STEP OPEN = 0.1 % to 100.0 %
START STEP CLOSE = 0.1 % to 100.0 %
STOP STEP CLOSE = 0.0 % to 99.9 %

7.7.4 ON and OFF times setting

The ON or OFF times can be set individually for the directions OPEN and CLOSE.

➡ **Via the menu to parameter:**

MAIN MENU (M0)
 SETTINGS (M1)
 STEPPING MODE (M17)
 ON TIME OPEN (M1711)
 OFF TIME OPEN (M1712)
 ON TIME CLOSE (M1716)
 OFF TIME CLOSE (M1717)

EDIT

M1711

ON TIME OPEN

10.0 %

⬆

:EDIT

⬇:OK

C:ESC

EDIT

M1712

OFF TIME OPEN

50.0 %

⬆

:EDIT

⬇:OK

C:ESC

Default values:	ON TIME	OPEN = 10.0 s
	OFF TIME	OPEN = 50.0 s
Setting ranges:	ON TIME	CLOSE = 10.0 s
	OFF TIME	CLOSE = 50.0 s
Setting ranges:	ON TIME	OPEN = 1.0 to 300.0 seconds
	OFF TIME	OPEN = 1.0 to 300.0 seconds
	ON TIME	OPEN = 1.0 to 300.0 seconds
	OFF TIME	OPEN = 1.0 to 300.0 seconds

7.8 Local controls enable function (option)

The selector switch functions on the local controls (LOCAL, OFF, and REMOTE) may be either enabled or disabled.


7.8.1 Selector switch functions: enable/disable

This value is set in the factory and can only be changed by the AUMA service.



Via the menu to parameter:

MAIN MENU (M0)
CONFIGURATION (M4)
SETUP (M41)
ENABLE LOCAL MODE (M410W)



Default value: NOT ACTIVE



Description of the parameter settings:

NOT ACTIVE

All selector switch functions are enabled.

FOUNDATION FIELDBUS

This setting is only permissible if the local controls are equipped with a selector switch.

The selector switch function is enabled via the ENABLE_LOCAL_CONTROLS Foundation Fieldbus parameter of the APVB transducer block (index 785). The selector switch functions LOCAL, OFF, and REMOTE may be enabled or disabled either separately or combined. Please refer to "Manual (Device integration Fieldbus) AUMATIC AC 01.1/ACExC 01.1 Foundation Fieldbus".

The following fault signals are emitted if one out of the three selector switch positions is not enabled while the Foundation Fieldbus communication is active.

- Status indication S0: RESTRICTED.
- The Foundation Fieldbus APVB transducer block signals a fault via XD_ERROR (General Error, 17 (0x11)) and XD_ERROR_EXT (Not ready indication, 0x00000010), thus generating an operation mode change of the DOFB or AOFB to the IMan status.

If the communication via Foundation Fieldbus is not available, all three selector switch positions are enabled.

I/O INTERFACE


This setting is only permissible if the local controls are equipped with a selector switch.

The digital RELEASE input (refer to wiring diagram ACP) is used to enable or disable the actuator operation via the push buttons.

- Disabling operation via push buttons:
no signal at input RELEASE (the status indication S0 in the display shows RESTRICTED).
- Enabling operation via push buttons:
Apply + 24 V DC signal at the RELEASE input.

7.9 EMERGENCY STOP function (option)

As an option, the AUMATIC can be equipped with an EMERGENCY STOP push button. When engaged, this EMERGENCY STOP interrupts the 24 V AC control voltage of the contactors.



Information The EMERGENCY STOP push button is not available for the ACExC, but only for the weatherproof versions of the AUMATIC.

Table of contents:

7.9.1	Description of the functions
7.9.2	Feedback signals on the display
7.9.3	Feedback signals setting via output contacts
7.9.4	Feedback signal setting via LEDs

7.9.1 Description of the functions

As soon as this EMERGENCY STOP button is operated, several steps are performed in the AUMATIC:

- The 24 V AC control voltage of the AUMATIC contactors is interrupted.
- Switching off the operation command and cancelling a possibly set self-retaining.
- Option: The operation status of the EMERGENCY STOP button is indicated by activating an output contact.
- Option: The operation status of the EMERGENCY STOP button is indicated by an indication light (LED) lighting up on the local controls.
- EMERGENCY STOP status display indication with the EMCY STOP ACTIVE entry in the S3 diagnosis indication NOT READY IND
- Display indication on EMERGENCY STOP status in S0 status indication: Operation status EMERGENCY STOP
- The Foundation Fieldbus APVB transducer block signals a fault via XD_ERROR (General Error, 17 (0x11)) and XD_ERROR_EXT (Not ready indication, 0x00000010), thus generating an operation mode change of the DOFB or AOFB to the IMan status.



After unlocking the EMERGENCY STOP button, a possibly active operation command will **not immediately** be re-activated, but only upon confirmation by the user which, in turn, resets the EMERGENCY STOP status. After this, operation commands as well as emergency and failure operations will immediately be performed.

The acknowledgement is made:

- via the **Reset** push button in selector switch position LOCAL.
- via the APPLICATION_RESET Foundation Fieldbus parameter of the APVB transducer blocks (index 784).

7.9.2 Feedback signals on the display

The following indications are displayed in status indications S0 and S3:



Description of the displays:

EMERGENCY STOP/EMCY STOP ACTIVE


The EMERGENCY STOP button has been operated and has put the AUMATIC into the EMERGENCY STOP status. This status can only be cancelled by unlocking the EMERGENCY STOP button and issuing a subsequent RESET command.

7.9.3 Feedback signals setting via output contacts



Via the menu to parameter:

```
MAIN MENU (M0)
  SETTINGS (M1)
    I/O 1 (M14)
      OUTPUT CONTACT 1 - 5
```



Description of the parameter settings:

EMCY STOP BUTTON

The selected output contact is activated, after the EMERGENCY STOP button was operated.


This signal can be cancelled by unlocking the EMERGENCY STOP button.

7.9.4 Feedback signal setting via LEDs



Via the menu to parameter:

```
MAIN MENU (M0)
  SETTINGS (M1)
    LOCAL CONTROLS (M13)
      LED 1 - 4
```



Description of the parameter settings:

EMCY STOP BUTTON

The selected LED is illuminated after the EMERGENCY STOP button was operated.

This signal can be cancelled by unlocking the EMERGENCY STOP button.

7.10 Foundation Fieldbus interface

All Foundation Fieldbus interface settings (including the device address assignment) are made via the Foundation Fieldbus.

For this reason, the local operation (via the display) of the AUMATIC does not supply any Foundation Fieldbus relevant parameter.

In the following

MAIN MENU (M0)

SETTINGS (M1)

FF-INTERFACE 1 (M1M)

only those parameters are available used for setting both analogue inputs. These parameters only affect the local behaviour of the analogue inputs (e.g. when using as local analogue setpoint input). Irrespective of these parameter settings, the signal behaviour via Foundation Fieldbus is exclusively configured using the AIFB1 or AIFB2 function blocks.

7.11 External inputs for bus (option)

Parallel control via external inputs is possible for an AUMATIC with fieldbus interface.

Four binary 24 V DC inputs and two analogue 0/4 – 20 mA inputs are available.

Irrespective of the signal assignment of these inputs, the fieldbus communication with the DCS will remain intact.

7.11.1 Signals assignment for operation commands

This value is set in the factory.




Via the menu to parameter:

MAIN MENU (M0)

CONFIGURATION (M4)

SETUP (M41)

EXTERNAL INPUTS BUS (M410G)



Default value: STANDARD




Description of the parameter settings:

STANDARD

Figure 12:

The external input signals are transferred to the process control system via the fieldbus. They do not influence the operation behaviour of the actuator.

Figure 12



1 External inputs


2 Fieldbus interface

OPEN CLOSE CONTROL

Figure 13:

- Conventional control of the actuator is possible either in OPEN - CLOSE duty or in modulating duty (setpoint of 0/4 – 20 mA). Selection between open - close and modulating duty is made via the MODE input (refer to page 53).
- Operation commands can be issued via the fieldbus or via the external inputs. Switch-over is made via BUS/REMOTE input (see below).

Figure 13



1 External inputs


2 Fieldbus interface

OPEN CLOSE ESD

Figure 14:

- Actuator control is possible in open-close duty (OPEN - CLOSE - EMERGENCY) only. Modulating duty is not possible.
- Operation commands can be issued via the fieldbus or via the external inputs. Switch-over is made via BUS/REMOTE input (see below).
- Operation commands are made in push-to-run operation only.
- If a voltage of 0 V is present at EMERGENCY input, the actuator performs the programmed EMERGENCY operation, irrespective of the BUS/REMOTE input.

Figure 14




1 External inputs

2 Fieldbus interface

OPEN CLOSE STOP

Figure 15:

- Actuator control is possible in open-close duty (OPEN – CLOSE - STOP) only. Modulating duty is not possible.
- Operation commands can be issued via the fieldbus or via the external inputs. Switch-over is made via BUS/REMOTE input (see below).
- Operation commands are made in self-retaining only.

Figure 15

1 External inputs

2 Fieldbus interface

Information In the event of loss of bus communication, the external inputs do not automatically take over!

Information Please refer to the AUMATIC AC 01.1/ACExC 01.1 Foundation Fieldbus manual (Device integration Fieldbus) for details on feedback signals.

Switching between operation commands via fieldbus and external inputs

- Apply **0 V DC** (input open) at BUS/REMOTE input:
Controls react to fieldbus signals only.
- Apply **+ 24 V DC** at BUS/REMOTE input.
Controls reacts to external input signals only:
MODE, CLOSE, OPEN, STOP, EMERGENCY, ANIN1 (the available external inputs depend on the parameter setting).

7.12 Combination fieldbus/standard interface (option)

The actuator controls is equipped with both a fieldbus interface **and** a parallel interface, if the I/O STACK 2 parameter status shows I/O.



Via the menu to parameter:

MAIN MENU (M0)
CONFIGURATION (M4)
SETUP (M41)
I/O STACK 2 (M410Q)





Figure 17 shows an extract of the wiring diagram with fieldbus interface (1) and parallel interface (2):



Switching between operation commands via fieldbus and parallel inputs

- Apply **0 V DC** (input open) at BUS/REMOTE input:
Controls react to fieldbus signals only.
- Apply **+ 24 V DC** (optional 115 V AC) at BUS/REMOTE input:
Controls reacts to parallel interface signals only:
MODE, CLOSE, OPEN, STOP, EMERGENCY, ANIN1+, ANIN1–

Information If a voltage of 0 V is present at the EMERGENCY input, the actuator performs the set EMERGENCY operation (refer to page 34), irrespective of the BUS/REMOTE input.

Information In the event of loss of bus communication, the external inputs do not automatically take over!

Information Please refer to the AUMATIC AC 01.1/ACExC 01.1 Foundation Fieldbus manual (fieldbus device integration) for details on feedback signals.

7.13 Monitoring and failure functions**Table of contents:**

7.13.1 Torque monitoring
7.13.2 Motor protection (thermal monitoring)
7.13.3 Monitoring of the max. number of starts and the max. running time
7.13.4 Operating time monitoring
7.13.5 Reaction monitoring
7.13.6 Phase failure monitoring

7.13.1 Torque monitoring

The torque monitoring serves as overload protection over the whole travel. Depending on the version, the required tripping torques are either set via the torque switching in the actuator or via the OPENING and CLOSING parameters (Non-Intrusive version).

If the set torques are reached *in mid-travel*, the actuator will be stopped and the following fault signals will be sent:

- Status indication S0: operation mode OFF/LOCAL = FLT + NR
- Status indication S0/S6: operation mode REMOTE = FAULT IND.
- Status indication S1: TORQUE FAULT (OPEN) or TORQUE FAULT (CLOSE) (torque fault)
- The Foundation Fieldbus APVB transducer block signals a fault via XD_ERROR (General Error, 17 (0x11)) and XD_ERROR_EXT (Torque fault OPEN, 0x00000001 or Torque fault CLOSE, 0x00000002), thus generating an operation mode change of the DOFB or AOFB to the IMan status.

The fault has to be acknowledged before the operation can be resumed. The acknowledgement is made:

1. either by an operation command in the opposite direction.
 - For TORQUE FAULT (CLOSE): Operation command in direction OPEN
 - For TORQUE FAULT (OPEN): Operation command in direction CLOSE
2. or, in case the torque present is smaller than the preset tripping torque:
 - via the **Reset** push button in selector switch position LOCAL.
 - via the APPLICATION_RESET Foundation Fieldbus parameter of the APVB transducer block (index 784).

Setting the torque by-pass

The torque monitoring can be disabled during the set torque by-pass duration.

For this period, the torque by-pass is effective, irrespective of the actuator position.

NOTICE**Valve damage due to excessive torque!**

→ Only apply torque by-pass with the consent of the valve manufacturer.

**Via the menu to parameter:**

```

MAIN MENU (M0)
  SETTINGS (M1)
    TORQUE (M12)
      BY-PASS DURATION (M1212)

```

EDIT	M1212
BY-PASS DURATION	
0.0 S	
⬆:EDIT	⬆:OK C:ESC

Default value: 0.0 s

Setting range: 0 to 50 (= 0.0 to 5.0 seconds)

7.13.2 Motor protection (thermal monitoring)

In order to protect against overheating and impermissibly high temperatures at the actuator, PTC thermistors or thermoswitches are embedded in the motor winding. The thermoswitch is tripped as soon as the max. permissible winding temperature has been reached.

The actuator is switched off and the following signals are given:

- LED 3 (thermal fault) on the local controls is illuminated.
- Status indication S0: operation mode OFF/LOCAL = FLT + NR
- Status indication S0/S6: operation mode REMOTE = FAULT IND.
- The Foundation Fieldbus APVB transducer block signals a fault via XD_ERROR (General Error, 17 (0x11)) and XD_ERROR_EXT (Thermal fault, 0x00000200), thus generating an operation mode change of the DOFB or AOFB to the IMan status.

The motor has to cool down before the operation can be resumed. Depending on the parameter setting, the fault signal is either automatically reset or the fault signal has to be acknowledged.

The acknowledgement is made:

- via the **Reset** push button in selector switch position LOCAL.
- via the APPLICATION_RESET Foundation Fieldbus parameter of the APVB transducer block (index 784).


Viewing the motor protection

This value is set in the factory.



Via the menu to parameter:

```
MAIN MENU (M0)
  CONFIGURATION (M4)
    SETUP (M41)
      MOTOR PROTECTION (M4108)
```



Default values: Non Ex actuators = THERMAL CONT. (AUTO)
Ex actuators = THERMISTOR (RESET)



Description of the parameter settings:

THERMAL CONT. (AUTO)

Automatic reset after the motor has cooled down.
Not possible for explosion-proof version ACExC 01.1

THERMAL CONT. (RESET)

Manual reset. After the motor has cooled down the fault must be reset, either

- the **Reset** push button at the local controls, or
- with the RESET command via the fieldbus.

If required the thermal overload relay has to be reset manually. To this end, remove the cover on the back of the AUMATIC and operate the RESET button on the thermal overload relay.

THERMISTOR (RESET)

Manual reset. After the motor has cooled down the fault must be reset, either

- the **Reset** push button at the local controls, or
- with the RESET command via the fieldbus.

THERMISTOR (AUTO)

Automatic reset after the motor has cooled down.

Not possible for explosion-proof version ACExC 01.1

7.13.3 Monitoring of the max. number of starts per hour and max. running time per hour

The AUMATIC monitors any exceeding of

- the maximum number of starts (motor starts) per hour
- the maximum running time (on-time) per hour.

If any of these values has been exceeded, the actuator will however not be stopped, but the following warning signals are sent:

- Status indication S0: operation mode OFF/LOCAL = WRN + NR
- Status indication S0/S6: operation mode REMOTE = WARNING IND.
- Status indication S2: WARNING STARTS/RUN

The warning signals will automatically be cleared if the number of starts per second and the set max. running time per hour are no longer reached.

An exceeding is also logged in the operating data counters

WRN.STARTS/RUN1 and WRN.STARTS/RUN2 (page 78).

WRN.STARTS/RUN1 contains the total of all starts/running time warnings.

WRN.STARTS/RUN2 contains the max. time duration of a starts/running time warning.

Example:

The AUMATIC signals a total of 3 starts/running time warnings because of an exceeding of the set cycles/h or running time/h: once 20 min., once 15 min, once 22 min. Afterwards the operating data counters contain the following values:

WRN.STARTS/RUN1 = 57 min. = total of all time sections (20+15+22 min)

WRN.STARTS/RUN2 = 22 min. = longest time section

Switching on/off the monitoring of the max. number of starts and the max. running time

To be able to view settings or to perform modifications, the MONITORING parameter must be set to FUNCTION ACTIVE.

Information

This parameter is also used to switch the operating time monitoring (page 71) on or off.


**Via the menu to parameter:**

MAIN MENU (M0)

CONFIGURATION (M4)

SPECIAL FUNCTIONS (M40)

MONITOR TRIGGERS (M4016)



Default value: FUNCTION ACTIVE

**Description of the parameter settings:****FUNCTION NOT ACTIVE**

The MAX STARTS/HOUR and MAX DUTY CYCLE parameters are not shown in the display.

FUNCTION ACTIVE

The MAX STARTS/HOUR and MAX DUTY CYCLE parameters are shown in the display.

Setting the max. permissible number of starts



Via the menu to parameter:

MAIN MENU (M0)
 SETTINGS (M1)
 MONITOR TRIGGERS (M18)
 MAX STARTS/HOUR (M1810)

```
EDIT                M1810
MAX STARTS/HOUR
1200
◀:EDIT  ▶:OK  C:ESC
```

Default value: 1200
Setting range: 0 to 1800 starts (motor starts)

Setting the max. permissible running time



Via the menu to parameter:

MAIN MENU (M0)
 SETTINGS (M1)
 MONITOR TRIGGERS (M18)
 MAX DUTY CYCLE (M1811)

```
EDIT                M1811
MAX DUTY CYCLE
15 min
◀:EDIT  ▶:OK  C:ESC
```

Default value: 15 MIN



Description of the parameter settings:

15 MIN

The max. permissible running time (on-time) per hour amounts to 15 min.

24 MIN

The max. permissible running time (on-time) per hour amounts to 24 min.

30 MIN

The max. permissible running time (on-time) per hour amounts to 30 min.

7.13.4 Operating time monitoring

This function allows the monitoring of the operating time of the actuator. If the actuator needs longer than the set time (MAX. RUN TIME parameter) to move from end position OPEN to end position CLOSED, the following warning signals are given (the actuator is not stopped):

- Status indication S0: operation mode OFF/LOCAL = WRN + NR
- Status indication S0/S6: operation mode REMOTE = WARNING IND.
- Status indication S2: WARNING OPER. TIME

The warning signals are automatically cleared when a new operation command is executed.


When the actuator moves from an intermediate position to an end position, the set monitoring time for the whole stroke is assigned in relation to the remaining stroke/travel.

Switching the operating time monitoring on/off**Information**

This parameter is also used to switch the monitoring of the max. number of starts per hour and the max. running time per hour (page 67) on/off.

**Via the menu to parameter:**

```
MAIN MENU (M0)
  CONFIGURATION (M4)
    SPECIAL FUNCTIONS (M40)
      MONITOR TRIGGERS (M4016)
```



Default value: FUNCTION ACTIVE

**Description of the parameter settings:****FUNCTION NOT ACTIVE**


The operating time monitoring is switched off.

FUNCTION ACTIVE

The operating time monitoring is switched on.

Setting the max. permissible operating time**Via the menu to parameter:**

```
MAIN MENU (M0)
  SETTINGS (M1)
    MONITOR TRIGGERS (M18)
      MAX. RUN TIME (M1812)
```



Default value: 900 s

Setting range: 4 to 36000 seconds (4 seconds to 10 hours)

7.13.5 Reaction monitoring

The AUMATIC controls monitor the actuator reaction via the control unit of the actuator.

If no reaction is recorded at the output drive of the actuator within a set time (REACTION TIME parameter), the actuator is switched off and the following fault signals are given:

- Status indication S0: operation mode OFF/LOCAL = FLT + NR
- Status indication S0/S6: operation mode REMOTE = FAULT IND.
- Status indication S1: INTERNAL FAULT
- Diagnostics indication D2: NO REACTION
- The Foundation Fieldbus APVB transducer block signals a fault via XD_ERROR (Electronics Failure, 20 (0x14)) and XD_ERROR_EXT (Internal electronics error, 0x00040000), thus generating an operation mode change of the DOFB or AOFB to the IMan status.

The fault has to be acknowledged. The acknowledgement is made:

- via the **Reset** push button in selector switch position LOCAL.
- via the APPLICATION_RESET Foundation Fieldbus parameter of the APVB transducer block (index 784).

In case of operation from an intermediate position, reaction monitoring will only be performed if the actuator has a position feedback.

Switching the reaction monitoring on/off

This value is set in the factory and may not be changed.



Via the menu to parameter:

```
MAIN MENU (M0)
  CONFIGURATION (M4)
    SPECIAL FUNCTIONS (M40)
      REACTION MONITORING (M4018)
```

```

EDIT          M4018
REACTION MONITORING
FUNCTION NOT ACTIVE
⬆:EDIT  ⬇:OK  C:ESC
```

Default value: FUNCTION NOT ACTIVE



Description of the parameter settings:

FUNCTION NOT ACTIVE

The reaction monitoring is switched off.

FUNCTION ACTIVE

The reaction monitoring is switched on.

Setting/editing the reaction time

The reaction time is set in the factory.



Via the menu to parameter:

```
MAIN MENU (M0)
  SETTINGS (M1)
    REACTION TRIGGER (M1H)
      REACTION TIME (M1H10)
```

```

EDIT          M1H10
REACTION TIME
7.0 s
⬆:EDIT  ⬇:OK  C:ESC
```

Default value: 7 s

Setting range: 1.0 to 15.0 seconds

7.13.6 Phase failure monitoring

When connected to a 3-phase AC power supply, the electronics is supplied via two of the three phases. In case of losing one of the two phases, the controls are inoperable and the actuator stops.

The AUMATIC monitors the third phase. If the third phase fails, the controls remain fully operable. The controls stop the actuator in case of third phase loss and the following fault signals are generated:

- Status indication S1: PHASE FAILURE.
- The Foundation Fieldbus APVB transducer block signals a fault via XD_ERROR (General Error, 17 (0x11)) and XD_ERROR_EXT (Loss of phase, 0x00000100), thus generating an operation mode change of the DOFB or AOFB to the IMan status.

Information

In case of one phase loss during motor operation, this does not necessarily lead to an immediate standstill of the actuator. The reason is that the rotating motor generates the missing phase itself. This leads, however, to a reduction of the motor output torque.

If the third phase fails and the torque is still sufficient for valve operation, the missing third phase is only detected when switching off (e.g. in an end position) and above mentioned fault signals are generated.

Setting/editing the phase monitoring


Faults in supply voltage (e.g. voltage drops) do not generate a fault signal during the period adjustable for this parameter.

**Via the menu to parameter:**

MAIN MENU (M0)

SETTINGS (M1)

PHASE MONITORING (M10)



Default value: 10.0 s

Setting range: 0.0 to 30.0 seconds

Information

The phase loss monitoring is only valid for connections to 3-phase AC power supplies. The phase loss monitoring is not available for the following versions:

Numbering system of wiring diagram:

- 3rd position in ACP wiring diagram = I, Q (DC motor)
- 5th position in ACP wiring diagram = B (heater with external supply)
- 6th position in ACP wiring diagram = 7 (external supply of electronics with 24 V DC, without transformer, without voltage output)

Example: ACP 11I2B7P0CA-002

Numbering system of terminal plan:

- KMS 44TP in terminal plan = 44 (motor connection via terminal box), example: KMS 44TP502/001
- KMS 44TP in terminal plan = 42 (motor connection via plug/socket connector), example: KMS 42TP480/001

8 Corrective action

8.1 Fault indications and warning indications

Faults interrupt or prevent electrical actuator operation.

Warnings have no influence on the electrical actuator operation. They only serve information purposes.

Fault and warning indications are shown on the display.

Table of contents:

8.1.1 Status indication S0 - Faults and warnings


8.1.2 Status indication S1 - Faults

8.1.3 Status indication S2 - Warnings

For further status indications in the display, refer to page 15 et seqq.

8.1.1 Status indication S0 - faults and warnings

Line 4 of status indication S0 shows faults and warnings.



Description of the fault indications:

FAULT IND.

A fault has occurred

→ For further information, press ▼▲ and go to status indication S1.

WARNING IND.

A warning has occurred

→ For further information, press ▼▲ and go to status indication S2.

FAULT + WARNING

Faults as well as warnings have occurred.

→ For further information, press ▼▲ and go to status indication S1 (faults) or S2 (warnings).

NOT READY IND.

The actuator cannot be operated from REMOTE. The actuator can only be operated via the local controls.

→ For further information, press ▼▲ and go to status indication S3 (cause of fault signals).

FLT + NR

Faults and the NOT READY IND. signal have occurred.

→ For further information, press ▼▲ and go to status indications S1 or S3.

WRN + NR

Faults and the NOT READY IND. signal have occurred.

→ For further information, press ▼▲ and go to status indications S2 or S3.


FLT + WRN + NR

Faults, warnings, and the NOT READY IND. signal have occurred.

→ For further information, press ▼▲ and go to status indication S1 to S3.

8.1.2 Status indication S1 - faults

Faults are indicated within this group:

**Description of the fault indications:****NO FAULT**

No fault has occurred.

INTERNAL FAULT

Internal fault has occurred.

For further information:

1. Go to group D0: Press **C** and hold down until the diagnostic indication D0 is displayed.
2. Go to diagnostic indication D2 : Press ▼ twice.

TORQUE FAULT (CLOSE

Torque fault in direction CLOSE.

- Operation command in direction OPEN, or
- Set selector switch to position **Local control** (LOCAL) and reset fault indication via **Reset** push button, or
- Issue reset command via fieldbus.

TORQUE FAULT (OPEN)

Torque fault in direction OPEN

- Operation command in direction CLOSE, or
- Set selector switch to position **Local control** (LOCAL) and reset fault indication via **Reset** push button, or
- Issue reset command via fieldbus.

LOSS OF PHASE

One phase is missing.

- Test/connect phases.

THERMAL FAULT

Motor protection tripped.

- Cool off, wait.
 - If the fault indication display persists after cooling off:
 - Set selector switch to position **Local control** (LOCAL) and reset fault indication via **Reset** push button
 - Issue reset command via fieldbus.
- Check fuse F4.

CONFIGURATION FAULT


The controls' configuration is incorrect.

For further information:

- Cool off, wait.
- 1. Go to group D0 : Press **C** and hold down until the D0 diagnostic indication is displayed.
- 2. Go to diagnostic indication D4 : Press ▼ four times.

8.1.3 Status indication S2 - warnings

Warnings are indicated within this group:



Description of the warnings:

NO WARNING

No warnings have occurred.

WARNING RUN.TIME

The preset running time for a travel between end position OPEN and end position CLOSED has been exceeded.

- Set the running time (MONITOR TRIGGERS parameter) in accordance with the actual running time.
- Check tripping behaviour of end position switches.
- Check actuator mechanics.

WARNING STARTS/RUN

The preset values for max. starts/h or max. running time/h have been exceeded.

- Check modulating behaviour.
- Increase dead time.
- Reduce number of setpoint changes.

INTERNAL FEEDBACK

Position transmitter (potentiometer or RWG) is not standardised.

- Operate actuator into both end positions (OPEN and CLOSED), one after the other.

INTERNAL WARNING

Internal warnings have occurred.

For further information:

1. Go to group D0: Press **C** and hold down until the D0 diagnostic indication is displayed.
2. Go to diagnostic indication D3 : Press **▼** three times.

FEEDBACK E2 LOSS

Signal loss of position transmitter.

- Check position transmitter signal.
- 1. Go to group D0: Press **C** and hold down until the diagnostic indication D0 is displayed.
- 2. Go to diagnostic indication D7 , D8, or D9 . Press **▼** either seven, eight, or nine times.
- Check position transmitter wiring (potentiometer or RWG).
- Check POSITION E2 parameter. The setting must correspond to the wiring diagram.

SETPOINT E1 LOSS

Signal loss of the set point.

- Check wiring.

TORQUE E6 LOSS

Signal loss of torque source.

- Check wiring.

I/O1 ANALOG IN1 LOSS

Signal loss of parallel interface of analogue input 1 (only for fieldbus/standard interface combinations, page 66).

- Check wiring.

I/O1 ANALOG IN2 LOSS

Signal loss of parallel interface of analogue input 2 (only for fieldbus/standard interface combinations, page 66).

→ Check wiring.

P-FEEDBACK E4 LOSS

Signal loss of process feedback E4 (only if process controller of logic sub-assembly is available and active).

→ Check wiring.

FIBRE OPTIC LOSS

Signal loss of fibre optic cable (only for bus with fibre optic loop topology).

→ Check wiring.

ANALOG IN1 BUS1 LOSS

Signal loss of analogue input 1.

→ Check wiring.


ANALOG IN2 BUS1 LOSS

Signal loss of analogue input 2.

→ Check wiring.

8.1.4 Status indication S3 - causes for not ready remote

The causes for the NOT READY IND. fault signals (status indication S0) are indicated within this group.



Description of the fault indications:

READY

Actuator can be operated from REMOTE.

NOT REMOTE

Actuator **cannot** be operated from REMOTE.

Possible causes:

Selector switch in position LOCAL or OFF.

WRONG COMMAND

Indicates the fact that several operation commands were received simultaneously via the fieldbus (e.g. REMOTE OPEN and REMOTE CLOSE simultaneously or REMOTE CLOSE/REMOTE OPEN and REMOTE SETPOINT (nominal) simultaneously) or that the max. value for a nominal position has been exceeded.

EMERGENCY MODE

The operation mode EMERGENCY is active.

EXTERNAL CONTROLS BUS

For combination fieldbus/standard interface function:

Operation via parallel interface.

EMCY STOP ACTIVE

The EMERGENCY STOP button has been operated.

ACTUATOR LOCKED

The actuator is locked (only set for special applications, e.g. bypass function).

8.2Diagnostics

Table of contents:

8.2.1	Operating data logging
8.2.2	Diagnostic indication (D) via the display

8.2.1Operating data logging


The operating data provides details e.g. about the running time, the number of starts, number of torque faults etc.
The analysis of this data provides valuable information regarding the optimization of both actuator and valve. When using this information purposefully, actuator and valve will be carefully operated, e.g. through appropriate parameter setting.
In case of fault, the logging of operating data makes a quick error diagnostics possible.

Enable viewing

The OPERATIONAL DATA configuration must be set to VIEW ENABLED:

- ➡
- Via the menu to parameter:

MAIN MENU (M0)
CONFIGURATION (M4)
SPECIAL FUNCTIONS (M40)
OPERATIONAL DATA (M4012)



Default value: VIEW ENABLED

- ↓
- Description of the parameter settings:


VIEW NOT ENABLED
The operational data is not indicated in the display

VIEW ENABLED
The operational data is indicated in the display

Viewing the operational data

- ➡
- Via the menu to parameter:

MAIN MENU (M0)
OPERATIONAL DATA (M2)



Various data is monitored by the AUMATIC and saved to a non-volatile memory (EEPROM). Two counters are provided, one of them is erasable. The recorded data can be read and deleted via the display. The access right for deletion is password-protected.


Table 10	
Operational data	
TOTAL MOTOR RUNTIME	Motor running time in the complete lifetime
MOTOR RUNTIME	Reset to 0 possible
TOTAL STARTS	Number of start (motor starts) in the complete lifetime
STARTS	reset to 0 possible
TOTAL TSC STOPS	Number of torque switch trippings in direction CLOSE in the complete lifetime
TSC STOPS	Reset to 0 possible
TOTAL LSC STOPS	Number of limit switch trippings in direction CLOSE in the complete lifetime
LSC STOPS	reset to 0 possible
TOTAL TSO STOPS	Number of torque switch trippings in direction OPEN in the complete lifetime
TSO STOPS	Reset to 0 possible
TOTAL LSO STOPS	Number of limit switch trippings in direction OPEN in the complete lifetime
LSO STOPS	Reset to 0 possible
TOTAL TSC FAULTS	Number of torque faults in direction CLOSE in the complete lifetime
TSC FAULTS	Reset to 0 possible
TOTAL TSO FAULTS	Number of torque faults in direction OPEN in the complete lifetime
TSO FAULTS	Reset to 0 possible
TOTAL THERMAL FLT.	Number of thermal faults (motor protection) in the complete lifetime
THERMAL FAULTS	Reset to 0 possible
TOT.WRN.STARTS/RUN1	Total of all time sections during which a start/run warning was signalled in the complete lifetime.
WRN.STARTS/RUN1	Reset to 0 possible
TOT.WRN.STARTS/RUN2	Max. time section during which a start/run warning was signalled in the complete lifetime.
WRN.STARTS/RUN2	Reset to 0 possible
TOTAL NO. POWER ON	Number of all system starts in the complete lifetime
NO. POWER ON	Reset to 0 possible

8.2.2 Diagnostic indications (D) via the display

The information contained in the diagnostic indications is only provided for the AUMA service and for enquiries in the factory.

1. Change from the status indications (group S) to the diagnostic indications (group D): Press **C** push button and hold it down until the group D0 appears (menu M is hereby skipped).
2. To return to the status indications:
Press **C** push button briefly once.

Wiring of the end position inputs (D0)



Description of the displays:


PULL DOWN INPUTS

Pull Down resistors are used for the inputs of the end position signals (limit and torque switches) on the logic board.

PULL UP INPUTS

Pull Up resistors are used for the inputs of the end position signals (limit and torque switches) on the logic board.

Actuator signals (D1)



Description of the displays:

NO SIGNALS

No actuator signals set

TSC (DSR)

Torque signal CLOSED in actuator tripped (not stored)

TSO (DOEL)

Torque signal OPEN in actuator tripped (not stored)

LSC (WSR)

Limit switching CLOSED in actuator tripped


LSO (WOEL)

Limit switching OPEN in actuator tripped

THERMAL FAULT

Motor protection tripped. Remedy:

Wait for cool-down; the signal is then either cancelled automatically or if not, bring selector switch to position **Local operation** and operate **Reset** push button. Check fuse F4.

Internal faults (D2)**Description of the displays:****NO INTERNAL FAULT**

No internal fault has occurred

THERMISTOR

A fault in the TMS tripping device was detected during start-up. Remedy: Check wiring diagram and MOTOR PROTECTION (M4108)). Check TMS tripping device.

SELECTOR SWITCH

The selector switch recognition is defective (no Hall sensor is tripped or more than one Hall sensor is tripped). Remedy: Check local control board, check mechanical attachment of the local controls in the housing

OUTPUT TRANSISTOR

The output of the operation commands to the relay board is defective, remedy: Check logic board and relay board

I/O1 CAN

No communication to parallel interface available. Remedy: Setting of I/O1 STACK 1 (M4106) must be in accordance with the wiring diagram, check wiring, check parallel interface

PHASE DETECTION

The phase sequence detection on the power supply is defective. Remedy: Check phase sequence detection, check wiring

24VDC FAULT

The internal 24 V supply of the AUMATIC is not within the supply voltage limits. Remedy: Check supply voltage, check power supply unit, check wiring of the AUMATIC voltage supply.

LOGIC CAN

The logic cannot establish any communication

NO REACTION

Fault signal of the reaction monitoring

MWG CAN

No communication to MWG available. Remedy: The I/O STACK 1 (M4106) setting must be in accordance with the wiring diagram; check wiring, check MWG.


MWG DEFECTIVE

The internal diagnostics of the MWG have detected a fault. Remedy: Replace/reconfigure MWG.

LOCAL CONTROL FAULT

Hardware fault of the local controls.

Internal warnings (D3)



Description of the displays:


NO INTERNAL WARNING

No internal warnings have occurred

NO FACTORY PARAMS

No valid factory settings are available.

Configuration fault (D4)



Description of the displays:

NO FAULT

AUMATIC has been correctly configured.

ENDPOS. INPUTS

The LIMIT/TORQUE-SWITCH parameter setting does not correspond to the ENDPOS. INPUTS parameter configuration (can only be modified by the AUMA service).


NO SWITCHING OFF

The LIMIT/TORQUE-SWITCH parameter setting does not correspond to the CONTROL UNIT) parameter configuration (can only be modified by the AUMA service).

E1-IN NOT EXISTING

The SETPOINT E1 parameter setting does not correspond to the I/O STACK 1 (M4106) parameter configuration (can only be modified by the AUMA service).


Hardware version of the logic (D5)




Description of the display:

LOGIC HRDWR. VER


Display of hardware version of the logic

Software version of the logic (D6)**Description of the display:****LOGIC SFTWR. VER**

Display of software version of the logic


Potentiometer value (D7)**Description of the display:****POT. VALUE**

The voltage values are displayed here if a potentiometer is installed:
in line 2 the value in end position CLOSED,
in line 3 the current value and
in line 4 the value in end position OPEN

RWG value (D8)**Description of the display:****RWG VALUE**

The current values are displayed here if an RWG is installed:
in line 2 the value in end position CLOSED,
in line 3 the current value and
in line 4 the value in end position OPEN

MWG value (D9)




Description of the display:

MWG VALUE

The current values are displayed here if an MWG is installed:
in line 2 the value in end position CLOSED,
in line 3 the current value and
in line 4 the value in end position OPEN

MWG hardware version (DA)




Description of the display:

MWG HRDWR.VER.

Hardware version of the MWG

MWG software version (DB)




Description of the display:

MWG SFTWR.VER.

Software version of the MWG

MWG status (Dd)



Description of the displays:

MWG OK

MWG is working, no faults.

HALLSENSOR ERROR

Remedy: Exchange MWG.

E2PROM ERROR

Remedy: Exchange MWG.

NOT CALIBRATED

Remedy: Re-calibrate MWG (can only be performed in the factory).

NO POSITION REFEREN.

Remedy: Re-calibrate MWG (can only be performed in the factory).

TORQUE SYSTEM FAULT


Remedy: Exchange MWG.

NO ENDPOSITIONS

Remedy: Re-set limit end positions (can only be performed in the factory).


NO TORQUE LIMITS

Remedy: Re-set torque pivot points (can only be performed in the factory).


Positioner (DF)**Description of the display:****POSITIONER**

Determined values of the adaptive positioner.

Line 2: inner deadband CLOSED, line 3: outer deadband, line 4: inner dead band OPEN.

E1 value (DJ)**Description of the display:****E1 VALUE**

Shows setpoint E1 in mA (only for standard I/O interface)

Internal fault 2 (DQ)**Description of the displays:****RAM FAILURE**

RAM of the logic defective.

Remedy: Replace logic.


EEPROM FAILURE

EEPROM of the logic defective. Remedy: Check logic, if necessary exchange Eeprom.

FF CAN

No communication to the Foundation Fieldbus interface available. Remedy:
I/O STACK 1 (M4106) must agree with the wiring diagram. Check wiring. Check I/O interface.

Bluetooth hardware version (D14)




Description of the display:

BT-OSS-HW-VERSION

Hardware version of the Bluetooth local controls

Bluetooth software version (D15)




Description of the display:

BT-OSS-SW-VERSION

Software version of the Bluetooth local controls

Bluetooth status (D16)




Description of the displays:

BLUETOOTH READY


Bluetooth connection available.

BLUETOOTH NOT RDY


No Bluetooth connection available.

FF hardware version (De)**Description of the display:****FF HRDWR.VER.**


Hardware version of the Foundation Fieldbus interface

FF software version (Df)**Description of the display:****FF SFTWR.VER.**

Software version of the Foundation Fieldbus interface


FF device ID (Dg)**Description of the displays:****FF-DEVICE_ID**

The device ID is a worldwide unambiguous device identification. It serves the purpose of recognising a Foundation Fieldbus device by means of the fieldbus and, therefore, cannot be modified. The device ID comprises 32 characters and consists of the manufacturer ID (0x0A01FF), the device type (0x01F8), the text -AUMA-AC01-, as well as the AUMATIC works number.

FF PD tag (Dh)**Description of the display:****FF-PD_TAG**

The PD Tag (Physical Device Tag) is the physical device name. The PD Tag comprises 32 characters and consists of the text AUMATIC -AC01- and the works number as default, when leaving the factory. The PD Tag serves the purpose of device identification within a plant and, therefore, the user may adapt the identification via Foundation Fieldbus as required.

FF node address (Di)



↓ Description of the display:

NODEADDRESS

The current device address as decimal and hexadecimal value.


Stationmode

- : BASIC, when configuring the AUMATIC as Basic Device.
- : LM, when configuring the AUMATIC as Link Master Device.
- : LAS, if the AUMATIC has been configured as Link Master device and is working as LAS (Link Active Scheduler).

MACROCYLCE

The preset macro cycle of the Foundation Fieldbus (unit 1/32 ms).

FF bus status (Dj)



↓ Description of the displays:

DATA EX

Indicates active actuator controls via the Foundation Fieldbus interface; for this, the APVB transducer block must be activated in AUTO and the DOFB or AOFB within the AUMATIC must be included in the FF Scheduling. Thus, DATA EX signals an operable local Foundation Fieldbus application within the AUMATIC.

BUS ACTIVE

Indicates, that besides the AUMATIC, further Foundation Fieldbus devices are connected to the same bus. This indicates correct wiring. To ensure perfect function in combination with other devices, both DATA EX and BUS ACTIVE must be set.

FF schedule list Dk

FF-SCHEDULELIST					Dk
AO	DO	PID	DI	AI	
1	1	1	123	1234	
Y	N	Y	NYN	YNYN	

↓ **Description of the displays:**

FF-SCHEDULELIST

The FF schedule list comprises the AUMATIC function blocks which can be called up within the AUMATIC due to a function block application configured by the user and loaded into the AUMATIC.

The transducer blocks pertaining to the function blocks are not shown, as they are directly called up by the used function blocks; the same is valid for the resource block not being shown, as it will be automatically called up within the AUMATIC.

The character below the function block number indicates, whether the respective function block is being called up within the AUMATIC or included in the FF Scheduling (“Y”) or not (“N”).

FF mode block DI

FF-MODE_BLK				DI
AO	PRA1	A3	D2	
@A	CAAA	AA	AA	
CA	CAAA	AA	OO	

← Target
← Actual

01 2345 67 89

0	AOFB	5	AITB1
1	APVB	6	AIFB3
2	PID	7	AITB3
3	RESOURCE	8	DIFB2
4	AIFB1	9	DITB2

↓ **Description of the displays:**


This display shows the target and actual operation modes of all function blocks called up within the AUMATIC. The pertaining transducer block is shown with each function block (exceptions: resource block and PID function block).

Only those function blocks are shown being called up in the AUMATIC. The following identifications are used for the target and actual operation modes of the function blocks:

r	ROut	Remote Output
R	RCas	Remote Cascade
C	Cas	Cascade
A	Auto	Automatic
M	Man	Manual
L	LO	Local Override
I	IMan	Initialisation Manual
O	OOS	Out of Service
@	AUTO+CAS	Automatic and Cascade

This way, the states of all function blocks can be shown on one display page.


FF APVB-XD error Dm



Description of the displays:

Actuator problems or fault signals are signalled back to the function blocks via the transducer blocks. The faults occurred are shown in the transducer blocks by means of the variables XD_ERROR and XD_ERROR_EXTENDED. The most important actuator fault signals are combined via the APVB and transferred to the DOFB or AOFB, which will in turn take on a safe operation status. The contents of these two variables are shown on the FF-APVB_XDERROR diagnostic page. For further references regarding the interpretation of the error codes shown, please refer to the "Manual (Device integration Fieldbus) AUMATIC AC 01.1/ACExC 01.1 Foundation Fieldbus". Any existing error is simultaneously shown via the hitherto existing status and diagnostic displays of the AUMATIC.

FF live list Dn



Description of the displays:

This diagnostic displays lists the first 15 device addresses comprised within the Foundation Fieldbus system. The comma after the last displayed device address indicates that further participants are available. It is only possible to dress the live list, if the AUMATIC is operated as Link Master Device (LM); otherwise the following is displayed:
BASIC MODE, NO LIVE_LIST

8.3 Troubleshooting

8.3.1 Problems with position feedback/indication E2 (from actuator)

- Check FEEDBACK E2 (M4101) parameter, page 27):
Value must correspond to the installed position transmitter.
- Check I/O1 ANALOG OUT1 (M410A) parameter:
Value must correspond to wiring diagram.
- Check I/O ANALOG OUT1 TYPE (M410A) parameter:
Value must correspond to desired feedback.
- Check fieldbus configuration
- Check diagnostic indications D7 or D8 (depending on the type of position transmitter installed in the actuator):
The value in the upper line is the raw value in the end position CLOSED, the value in the bottom line is the raw value in the end position OPEN while the value in the middle line is the current position transmitter raw value (it must change evenly throughout the complete stroke when the output drive shaft is turning).
- For torque seating:
Set limit end position as close as possible to torque switching off point
- Check galvanically isolated 24 V DC supply of the position feedback

8.3.2 Display hardly readable or illegible

- Check AUMATIC 24 V voltage supply (e.g. when switching on, all LEDs of the local controls must briefly light up, if necessary, check fuses).
- Change LCD contrast (for green display only). For this, change LCD CONTRAST (M011) parameter (the higher the value the darker the display).

8.3.3 Actuator does not run

- Check motor voltage supply.
- Check AUMATIC 24 V voltage supply (e.g. when switching on, all LEDs of the local controls must briefly light up, if necessary, check fuses).
- Check fault signals (status indication S1 or diagnostic indication D2).
Actuator cannot be operated when fault signals have occurred.

8.3.4 Actuator does only operate from local

- Check setting of I/O STACK 1 (M4106). The setting must correspond to wiring diagram.
- Check NOT READY IND. (status indication S3) indication.

8.3.5 Actuator is not switched off by limit seating in direction CLOSE or OPEN

- The actuator is set to torque seating.
Set actuator to limit seating:
- Set parameter CLOSED POSITION (page 40) to LIMIT.
 - Set parameter OPEN POSITION (page 40) to LIMIT.

Index

A		Functions of the AUMATIC	40	Output contacts	23
Actuator behaviour	35			Overrun (inner dead band)	51
Actuator reaction	38	I		P	
Adaptive behaviour	50	I/O stack 2	66	Password change	13
Alarm contact	25	Identification	7	Password entry	11
Analogue output 1 feedback signals	28	Indication lights	19	Phase failure monitoring	73
Analogue output 2 feedback signals	30	Indications	15	Position feedback signals	27
Analogue position feedback signal	29	Infra-red interface	12	Position transmitter	27
		Input MODE	53	Positioner	50
		Intermediate positions	43	Preset position	39
		Internet	7	PTC thermistors	68
		Intrusive	8	Push-to-run operation	9,32,33
B		L		R	
Blinker	21,26	Language change in the display	14	Range of application	6
Bluetooth interface	12	LCD contrast	14	Reaction monitoring	72
C		LEDs	19	Running indication	19,21,26
Collective fault signal	25	Limit seating	40	Running time per hour	69
COM-AC	12	Limit switching	42	Running time, max. permissible	70
COM-AC (software)	8	Local controls	9	S	
Combination fieldbus/standard interface	66	Local controls enable function	59	Safety instructions	5
Commission number	7	Logging of operating data	78	Self-retaining	9,32,33
Contrast	14	M		Setpoint E1	
Control	7	Max. error variable (outer dead band)	52	Input range	55
Corrective action	74	Max. permissible operating time	71	Source	54
D		MODE input	53	Short description	8
Dead band	51	Monitoring functions	67	Signals	22
Dead time	52	Motor protection	68	Signals via fieldbus	22
Delay time	39	Motor protection by-pass	36	Size	7
Diagnostics	78	Multiport valve function	47	Source for initiation	38
Display - indications	15	N		Status indication	15
E		Name plate	7	Stepping mode	56
Electronic name plate	17	Non-Intrusive	8	Stepping range	57
EMERGENCY behaviour	34,36	Non-Intrusive (version)	8	T	
EMERGENCY operation	34	Number of starts	69	Thermoswitches	68
EMERGENCY Position	36	O		Torque by-pass	67
EMERGENCY STOP function	60	OFF times	58	Torque E6	28
End position tolerance	53	ON times	58	Torque feedback signal	29
External inputs for bus	63	Open-close duty		Torque indication	16
F		Open-close duty - modulating		Torque monitoring	67
Failure behaviour	37	duty selection	53	Torque seating	40
Failure delay time	39	Operating time monitoring	71	Torque switching by-pass	36
Failure functions	67	Operation	9	Torque switching: check/set	41
Failure operation	38	Operation mode	31	Type	7
Failure position	38	Operation mode EMERGENCY	34	Type of seating	40
Failure source	38	Operation mode FAILURE	37	V	
Faults	74	Operation mode LOCAL	32	Valve position	15
Feedback E2	27	Operation mode OFF	31	W	
Feedback signals	27	Operation mode REMOTE	33	Warnings	74
Feedback via output contacts	23	Operation mode SETPOINT MODE	50	Wiring diagram (name plate)	7
Foundation Fieldbus interface	62				

Parameter index and display indications

A

ADAPTIVE BEHAVIOUR	50
ALARM CONTACT	25

B

BLINKER	21, 26
---------	--------

C

CHANGE PASSWORD	13
CLOSED POSITION	40, 42
CLOSING	41
CLOSING DEADBAND	51

D

DEAD TIME	52
DELAY TIME	39
DIAGNOSTIC INDICATIONS	
D0 - ENDPOS. INPUTS	80
D1 - ACTUATOR SIGNALS	80
D14 - BT-OSS-HW-VERSI	86
D15 - BT-OSS-SW-VERSI	86
D16 - BLUETOOTH STAT	86
D2 - INTERNAL FAULT	81
D3 - INTERNAL WARNINGS	82
D4 - CONFIGURATION	
FAULT	82
D5 - LOGIC HRDWR. VER	82
D6 - LOGIC SFTWR. VER	83
D7 - POT. VALUE	83
D8 - RWG VALUE	83
D9 - MWG VALUE	84
DA - MWG HRDWR. VER.	84
DB - MWG SFTWR. VER.	84
Dd - MWG STATUS	84
De - FF HRDWR. VER.	87
Df - FF SFTWR. VER.	87
DF - POSITIONER	85
Dg - FF-DEVICE_ID	87
Dh - FF-PD_TAG	87
DI - FF-NODE-ADDRESS	88
DJ - E1 VALUE	85
dj - FF BUS STATUS	88
Dk - FF-SCHEDULELIST	89
DI - FF-MODE_BLK	89
Dm - FF-APVB-XDERROR	90
Dn - FF-LIVE-LIST	90
DQ - INTERNAL FAULT	285
DIRECTION CLOSE	57
DIRECTION OPEN	57

E

EL. NAME PLATE	17
EMERG.SEL.SW.POS.	34
EMERGENCY BEHAVIOUR	35
EMERGENCY BY-PASS	36
EMERGENCY POSITION	35
ENABLE LOCAL MODE	59
EXTERNAL INPUTS BUS	63

F

FAILURE BEHAVIOUR	37
FAILURE POSITION	38
FAILURE SOURCE	38
FEEDBACK E2	27
FF ANLOG IN1 END	55
FF ANLOG IN1 START	55
FULL CLOSE ADJUST	53
FULL OPEN ADJUST	53

I

I/O 1	33
I/O ANLOG IN1 END	55
I/O ANLOG IN1 START	55
I/O1 ANALOG OUT1	28
I/O1 ANALOG OUT1 TYPE	29
I/O1 ANALOG OUT2	30
I/O1 ANALOG OUT2 TYPE	30
INTERMED. POSITION	43

L

LANGUAGE	14
LCD CONTRAST	14
LED 1 (LEFT HAND)	20
LED 2	20
LED 3	20
LED 4	20
LED 5 (RIGHT HAND)	20
LOCAL CLIENT	12

M

MAINTAINED LOCAL	32
MAINTAINED REMOTE	33
MAX DUTY CYCLE	70
MAX STARTS/HOUR	70
MAX. RUN TIME	71
MONITOR TRIGGERS	69, 70, 71
MOTOR PROTECTION	68

O

OFF TIME CLOSE	58
OFF TIME OPEN	58
ON TIME CLOSE	58
ON TIME OPEN	58
OPEN POSITION	40, 42
OPENING	41
OPENING DEADBAND	51
OPERATIONAL DATA	78
ORDER DATA	17
OUTER DEADBAND	52
OUTPUT CONTACT 1	23
OUTPUT CONTACT 2	23
OUTPUT CONTACT 3	23
OUTPUT CONTACT 4	23
OUTPUT CONTACT 5	23

P

POS NUMBER	49
POS. 1	44, 48
POS. DIRECTRUNNING	47
POS.1 BEHAVIOUR	45
POS.1 CONTROL	45
POS.1 SELECTOR SW	44
POSITIONER	48
PRESET POSITION	36, 39
PRODUCT DATA	17
PROJECT DATA	17

R

REACTION MONITORING	72
---------------------	----

S

SEATING MODE	40
SERVICE DATA	17
SET LIMIT SWITCHES	42
SETPOINT E1	54
START STEP CLOSE	57
START STEP OPEN	57
STEPPING MODE	56
STOP STEP CLOSE	57
STOP STEP OPEN	57

T

TORQUE	41, 67
TORQUE BY-PASS DURATION	67
TORQUE E6	28
TORQUE INDICATION	16

Europe

AUMA Riester GmbH & Co. KG

Plant Müllheim
DE-79373 Müllheim
Tel +49 7631 809 - 0
Fax +49 7631 809 - 1250
riester@auma.com
www.auma.com

Plant Ostfildern-Nellingen
DE-73747 Ostfildern
Tel +49 711 34803 - 0
Fax +49 711 34803 - 3034
riester@wof.auma.com

Service Center Cologne
DE-50858 Köln
Tel +49 2234 2037 - 9000
Fax +49 2234 2037 - 9099
Service@sck.auma.com

Service Center Magdeburg
DE-39167 Niederndodeleben
Tel +49 39204 759 - 0
Fax +49 39204 759 - 9429
Service@scm.auma.com

Service Center Bavaria
DE-85386 Eching
Tel +49 81 65 9017- 0
Fax +49 81 65 9017- 2018
Riester@scb.auma.com

AUMA Armaturentriebe GmbH
AT-2512 Tribuswinkel
Tel +43 2252 82540
Fax +43 2252 8254050
office@auma.at
www.auma.at

AUMA (Schweiz) AG
CH-8965 Berikon
Tel +41 566 400945
Fax +41 566 400948
RettichP.ch@auma.com

AUMA Servopohony spol. s.r.o.
CZ-10200 Praha 10
Tel +420 272 700056 / 704125
Fax +420 272 704125
auma-s@auma.cz
www.auma.cz

OY AUMATOR AB
FI-02230 Espoo
Tel +35 895 84022
Fax +35 895 8402300
auma@aumator.fi

AUMA France S.A.R.L.
FR-95157 Taverny Cedex
Tel +33 1 39327272
Fax +33 1 39321755
info@auma.fr
www.auma.fr

AUMA ACTUATORS Ltd.
GB- Clevedon North Somerset BS21 6QH
Tel +44 1275 871141
Fax +44 1275 875492
mail@auma.co.uk
www.auma.co.uk

AUMA ITALIANA S.r.l. a socio unico
IT-20023 Cerro Maggiore (MI)
Tel +39 0331 51351
Fax +39 0331 517606
info@auma.it
www.auma.it

AUMA BENELUX B.V.
NL-2314 XT Leiden
Tel +31 71 581 40 40
Fax +31 71 581 40 49
office@benelux.auma.com
www.auma.nl

AUMA Polska Sp. z o.o.
PL-41-310 Dabrowa Górnicza
Tel +48 32 261 56 68
Fax +48 32 261 48 23
R.Ludzien@auma.com.pl
www.auma.com.pl

OOO Priwody AUMA
RU-141400 Moscow region for mail: 124365 Moscow a/ya 11
Tel +7 495 221 64 28
Fax +7 495 221 64 38
aumarussia@auma.ru
www.auma.ru

ERICHs ARMATUR AB
SE-20039 Malmö
Tel +46 40 311550
Fax +46 40 945515
info@erichsarmatur.se
www.erichsarmatur.se

GRØNBECH & SØNNER A/S
DK-2450 København SV
Tel +45 33 26 63 00
Fax +45 33 26 63 21
GS@g-s.dk
www.g-s.dk

IBEROPLAN S.A.
ES-28027 Madrid
Tel +34 91 3717130
Fax +34 91 7427126
iberoplan@iberoplan.com

D. G. Bellos & Co. O.E.
GR-13671 Acharnai Athens
Tel +30 210 2409485
Fax +30 210 2409486
info@dgbellos.gr

SIGURD SØRUM A. S.
NO-1300 Sandvika
Tel +47 67572600
Fax +47 67572610
post@sigurd-sorum.no

INDUSTRA
PT-2710-297 Sintra
Tel +351 2 1910 95 00
Fax +351 2 1910 95 99
jpalhares@tyco-valves.com

MEGA Endüstri Kontrol Sistemleri Tic. Ltd. Sti.
TR-06810 Ankara
Tel +90 312 217 32 88
Fax +90 312 217 33 88
megaendustri@megaendustri.com.tr

CTS Control Limited Liability Company
UA-02099 Kiyiv
Tel +38 044 566-9971, -8427
Fax +38 044 566-9384
v_polyakov@cts.com.ua

Africa

AUMA South Africa (Pty) Ltd.
ZA-1560 Springs
Tel +27 11 3632880
Fax +27 11 8185248
aumasa@mweb.co.za

A.T.E.C.
EG- Cairo
Tel +20 2 3599680 - 3590861
Fax +20 2 3586621
atec@intouch.com

America

AUMA ACTUATORS INC.
US-PA 15317 Canonsburg
Tel +1 724-743-AUMA (2862)
Fax +1 724-743-4711
mailbox@auma-usa.com
www.auma-usa.com

AUMA Chile Representative Office
CL-9500414 Buin
Tel +56 2 821 4108
Fax +56 2 281 9252
aumachile@adsl.tie.cl

LOOP S. A.
AR-C1140ABP Buenos Aires
Tel +54 11 4307 2141
Fax +54 11 4307 8612
contacto@loopsa.com.ar

Asvotec Termointustrial Ltda.
BR-13190-000 Monte Mor/ SP.
Tel +55 19 3879 8735
Fax +55 19 3879 8738
atuador.auma@asvotec.com.br

TROY-ONTOR Inc.
CA-L4N 5E9 Barrie Ontario
Tel +1 705 721-8246
Fax +1 705 721-5851
troy-ontor@troy-ontor.ca

MAN Ferrostaal de Colombia Ltda.
CO- Bogotá D.C.
Tel +57 1 401 1300
Fax +57 1 416 5489
dorian.hernandez@manferrostaal.com
www.manferrostaal.com

PROCONTIC Procesos y Control Automático
EC- Quito
Tel +593 2 292 0431
Fax +593 2 292 2343
info@procontic.com.ec

IESS DE MEXICO S. A. de C. V.
MX-C.P. 02900 Mexico D.F.
Tel +52 55 55 561 701
Fax +52 55 53 563 337
informes@iess.com.mx

Corsusa International S.A.C.
PE- Miraflores - Lima
Tel +511444-1200 / 0044 / 2321
Fax +511444-3664
corsusa@corsusa.com
www.corsusa.com

PASSCO Inc.
PR-00936-4153 San Juan
Tel +18 09 78 77 20 87 85
Fax +18 09 78 77 31 72 77
Passco@prtc.net

Suplibarca
VE- Maracaibo Estado, Zulia
Tel +58 261 7 555 667
Fax +58 261 7 532 259
suplibarca@intercable.net.ve

Asia

AUMA Actuators (Tianjin) Co., Ltd.
CN-300457 Tianjin
Tel +86 22 6625 1310
Fax +86 22 6625 1320
mailbox@auma-china.com
www.auma-china.com

AUMA (INDIA) PRIVATE LIMITED
IN-560 058 Bangalore
Tel +91 80 2839 4655
Fax +91 80 2839 2809
info@auma.co.in
www.auma.co.in

AUMA JAPAN Co., Ltd.
JP-210-0848 Kawasaki-ku, Kawasaki-shi Kanagawa
Tel +81 44 329 1061
Fax +81 44 366 2472
mailbox@auma.co.jp
www.auma.co.jp

AUMA ACTUATORS (Singapore) Pte Ltd.

SG-569551 Singapore

Tel +65 6 4818750
Fax +65 6 4818269
sales@auma.com.sg
www.auma.com.sg

Al Ayman Industrial. Eqpts

AE- Dubai

Tel +971 4 3682720
Fax +971 4 3682721
auma@emirates.net.ae

PERFECT CONTROLS Ltd.

HK- Tsuen Wan, Kowloon

Tel +852 2493 7726
Fax +852 2416 3763
joeip@perfectcontrols.com.hk

DW Controls Co., Ltd.

KR-153-803 Seoul Korea

Tel +82 2 2113 1100
Fax +82 2 2113 1088/1089
sichoi@actuatorbank.com
www.actuatorbank.com

Al-Arfaj Engineering Co WLL

KW-22004 Salmiyah

Tel +965 481-7448
Fax +965 481-7442
info@arfajengg.com
www.arfajengg.com

Petrogulf W.L.L

QA- Doha

Tel +974 4350 151
Fax +974 4350 140
pgulf@qatar.net.qa

Sunny Valves and Intertrade Corp. Ltd.

TH-10120 Yannawa Bangkok

Tel +66 2 2400656
Fax +66 2 2401095
sunnyvalves@inet.co.th
www.sunnyvalves.co.th/

Top Advance Enterprises Ltd.

TW- Jhonghe City Taipei Hsien (235)

Tel +886 2 2225 1718
Fax +886 2 8228 1975
support@auma-taiwan.com.tw
www.auma-taiwan.com.tw

Australia

BARRON GJM Pty. Ltd.

AU-NSW 1570 Artarmon

Tel +61 294361088
Fax +61 294393413
info@barron.com.au
www.barron.com.au

2007-10-24



Solutions for a world in motion

AUMA Riester GmbH & Co. KG

Postfach 1362

D-79373 Müllheim

Tel +49 7631 809 - 0

Fax+49 7631 809 - 1250

riester@auma.com

www.auma.com



Y004.513/003/en/1.08