



Notes:

1. Metric tolerance per ISO 2768-m.
Dimensions in brackets [] are in inches and rounded to one decimal place.
2. See appropriate mounting flange drawing.
3. Seven inch minimum clearance recommended for removal of access cover and equipment adjustment.
4. Consult factory for more detailed dimensionals.
5. Actuator dimensions will not exceed drawing dimensions.

auma ACTUATORS INC.	SA (R) 07.1-07.5/ GS63.3 (STYLE RR-RL)		100MM COVER	JP 11/28/05	MX 11/28/05	5
	DESCRIPTION	BY/ DATE	APP/ DATE	REV		
REF. No. DK8P0R00	DWG. No. SD022000					