



Notes:

1. Metric tolerance per ISO 2768-m.  
Dimensions in brackets [ ] are in inches and rounded to one decimal place.
2. See appropriate mounting flange drawing.
3. Seven inch minimum clearance recommended for removal of access cover and equipment adjustment.
4. Consult factory for more detailed dimensionals.
5. Actuator dimensions will not exceed drawing dimensions.

<b>auma</b> ACTUATORS INC.	SA (R) 10.1 - AM02.1-100 GS100.3 (STYLE RR-RL)	REVISED CUSTOMER	MK	92	5
		COVER	11/19/05	11/23/05	
		DESCRIPTION	BY/ DATE	APP/ DATE	REV
		REF. No.	DRWR000	DWG. No.	SD027000