



Notes:

1. Metric tolerance per ISO 2768-m.
 Dimensons in brackets [] are in inches and rounded to one decimal place.
2. See appropriate mounting flange drawing.
3. Seven inch minimum clearance recommended for removal of access cover and equipment adjustment.
4. Consult factory for more detailed dimensionals.
5. Actuator dimensions will not exceed drawing dimensions.