



- Notes:
1. Metric tolerance per ISO 2768-m. Dimensions in brackets [ ] are in inches and rounded to one decimal place.
  2. See appropriate mounting flange drawing.
  3. Seven inch minimum clearance recommended for removal of access cover and equipment adjustment.
  4. Consult factory for more detailed dimensionals.
  5. Actuator dimensions will not exceed drawing dimensions.

<b>auma</b> ACTUATORS INC.	SA (R) 14.1-14.5 / GS125.3 AUMATIC (STYLE RR-RL)	FIRST ISSUE	BY	DATE	APP	DATE	REV
		03/06/08 03/06/08 03/06/08 0	D.JWSOROO SD111470				